

SONY[®]

Operating Instructions

Personal Entertainment Organizer

CLIE

PEG-N710C

Chapter 1

Basic operations of your
Sony CLIE Handheld

Chapter 2

Using basic applications

Chapter 3

Exchanging and updating
data using a HotSync[®]
operation

Chapter 4

Communicating using
your Sony CLIE Handheld

Chapter 5

Customizing your Sony
CLIE Handheld
(Preferences)

Chapter 6

Additional information

WARNING

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Owner's Record

The model number and serial number are located at the rear of the product. Record the serial number in the space provided below. Refer to them whenever you call upon your Sony dealer regarding this product.

Model No. PEG-N710C

Serial No. _____

The outlet shall be installed near the equipment and shall be easily accessible.

CAUTION

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by rotating the equipment off and on, the user is encouraged to try to correct the interference using one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

If you have question about this product, call the Sony Customer Information Center at keep on next line 1-877-760-7669; or write to the Sony Customer Information Center at 12451 Gateway Boulevard, Fort Myers, FL 33913. The number below is for FCC-related matters only.

Declaration of Conformity

Trade Name: SONY

Model No.: PEG-N710C

Responsible Party: Sony Electronics Inc.

Address: 680 Kinderkamack Road,
Oradell, NJ 07649 USA

Telephone No.: 201-930-6972

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

The supplied interface cable must be used with the equipment in order to comply with the limits for a digital device pursuant to Subpart B of Part 15 of FCC Rules.

On the supplied software

- Copyright laws prohibit reproducing the software or the software manual in whole or in part, or renting the software without the permission of the copyright holder.
- In no event will SONY be liable for any financial damage or loss of profits, including claims made by third parties, arising out of the use of the software supplied with this player.
- In the event a problem occurs with this software as a result of defective manufacturing, SONY will replace it at SONY's option or issue a refund. However, SONY bears no other responsibility.
- The software provided with this product cannot be used with equipment other than that which it is designated for use with.
- Please note that, due to continued efforts to improve quality, the software specifications may be changed without notice.

Program © 2001 Sony Corporation, © 2001 Palm, Inc. or its subsidiaries. All rights reserved.

Documentation © 2001 Sony Corporation

Sony, Memory Stick, the Memory Stick logo, Jog Dial, OpenMG, and PictureGear are trademarks of Sony Corporation.

Graffiti, HotSync, Palm Modem, and Palm OS are registered trademarks, and the HotSync logo and Palm are trademarks of Palm, Inc. or its subsidiaries.

IBM and PC/AT are registered trademarks of International Business Machines Corporation.

Microsoft, Windows, Outlook and the Windows 98 logo are registered trademarks of Microsoft Corporation.

MMX and Pentium are registered trademarks of Intel Corporation.

AvantGo, the AvantGo Client and the AvantGo logo are registered trademarks of AvantGo, Inc.

Pumatech, the Pumatech logo, Intellisync and Intellisync Lite are trademarks of Pumatech, Inc. that may be registered in some jurisdictions.

Adobe and Adobe Acrobat Reader are trademarks of Adobe Systems Incorporated.

QuickTime and the QuickTime logo are trademarks used under license. QuickTime is registered in the U.S. and other countries.

This product includes fonts owned by TypeBank Co., Ltd. under license.

RealJukebox is copyrighted by RealNetworks, Inc.

All other trademarks are trademarks of their respective owners.

CAUTION

Please contact your nearest Sony dealer regarding the problem you are experiencing with your Sony product.

Notes

- Sony does not support third-party add-on applications. If you are having a problem with a third-party application, please contact the developer or publisher of that software.
- The illustrations in this manual may differ from the actual software.
- Explanations in this manual assume that you are familiar with basic operations of Windows®. For how to use your computer and operating system, please refer to their respective manuals.

Before using your CLIE handheld, be sure to read the accompanying End-User's License Agreement.

Table of contents

About this manual	7
-------------------------	---

Chapter 1

Basic operations of your Sony CLIE Handheld

Turning on and off your Sony CLIE Handheld	9
Using the stylus	10
Using the Jog Dial™ navigator	12
Entering data into your Sony CLIE Handheld	13
Using Graffiti® writing to enter data	13
Using the onscreen keyboard	22
Using your computer keyboard	24
Changing the frontlight level	25
Resetting your Sony CLIE Handheld	26
Performing a soft reset	26
Performing a hard reset	27

Chapter 2

Using basic applications

 Managing schedules and events (Date Book)	29
Scheduling an event	29
Checking schedules	36
Editing Date Book events	42
Using the Date Book menus	47
 Managing addresses and phone numbers (Address Book)	49
Creating a new Address Book entry ..	49
Viewing Address Book entries	51
Editing Address Book entries	55
Using the Address Book menus	61

Managing tasks and things to do (To Do List)

Creating To Do List items	63
Viewing To Do List items	64
Checking off a To Do List item	65
Working with To Do List	66
Using the To Do List menus	70

Creating memos (Memo Pad)

Creating a new memo	71
Reviewing memos	73
Editing memos	76
Using the Memo Pad menus	78

Managing expenses (Expense)

Recording a new Expense item	79
Editing Expense items	81
Using the Expense menus	88

Using Calculator (Calc)

Calculating with Calculator	89
Using the Calculator buttons	90
Using the Calculator menus	90

Performing common tasks

Using the Application Launcher	91
Categorizing records	95
Finding records	98
Protecting your data (Security)	102
Attaching notes	108
Purging records	109
Using the Edit menu	110
Choosing fonts	111

Continued on next page

Table of contents

Chapter 3

Exchanging and updating data using a HotSync® operation

What is a HotSync® operation? 113

Performing a local HotSync® operation with the cradle 114

Using the Palm™ Desktop for CLIE software 116

Starting the Palm Desktop for CLIE software 116

Basic operations of the Palm Desktop for CLIE software 116

Locating the Palm Desktop for CLIE components 117

Advanced HotSync® operations ... 118

Setting the HotSync® setup options 118

Customizing HotSync application settings (Conduit) 120

Creating a user profile to control multiple CLIE handhelds 122

Conducting an IR HotSync operation 124

Conducting a HotSync operation via modem 127

Conducting a HotSync operation via a network 133

Importing data from a Windows application 136

Synchronizing with external data (File Link) 138

Chapter 4

Communicating using your Sony CLIE Handheld

Beaming between your Sony CLIE Handheld and another Palm OS® PDA 140

What you can do with beaming 140

Beaming information 141

Receiving beamed information 142

Tips on beaming information 142

Using "Memory Stick®" media 143

What is "Memory Stick®" media? 143

Inserting and removing "Memory Stick" media 144

Protecting the data in "Memory Stick" media 146

Starting an application automatically when "Memory Stick" media is inserted 146

Formatting "Memory Stick" media ... 147

Exchanging data via "Memory Stick®" media 149

Starting Memory Stick Gate (MS Gate) 149

Creating the default folder in "Memory Stick" media 152

Copying your CLIE handheld data to "Memory Stick" media 153

Copying data in "Memory Stick" media to your CLIE handheld 155

Deleting data in "Memory Stick" media 157

Using the MS Gate menus 159

How to read the online manual 160

Continued on next page

Table of contents

Chapter 5

Customizing your Sony CLIE
Handheld (Preferences)



**What you can do with
Preferences** 162

**Changing the Buttons
preferences** 164

Assigning applications to buttons ... 164

Changing the full-screen pen stroke
activities 165

Assigning applications to HotSync®
buttons 166

**Changing the Jog Dial™ navigator
preferences** 167

**Setting the display format of the time,
date, and numbers (Formats)** 168

Selecting a country default 168

Selecting the time, date, and numbers
formats 169

Setting the General preferences ... 170

Setting the time 170

Setting the date 171

Setting the automatic
shut-off time 172

Setting sounds 173

Turning on or off the Beam Receive
feature 174

Entering owner information 175

Creating Graffiti® ShortCuts 176

**Setting the High Resolution Assist
function** 178

Chapter 6

Additional information

**Backing up data of your Sony CLIE
Handheld** 180

Backing up data in your computer using
a HotSync operation 180

Backing up your CLIE handheld data
using “Memory Stick” media 181

**Using data of another Sony CLIE
Handheld** 183

Using the Palm Desktop for CLIE software
to transfer data 183

Using “Memory Stick” media to
transfer data 185

Precautions 187

Notes on use 187

Battery considerations 188

**Troubleshooting—Frequently Asked
Questions** 190

If you cannot perform a HotSync
operation 203

Getting Help 207

Specifications 208

Limited Warranty Statement 209

Index 213

About this manual

Welcome to the Sony Personal Entertainment Organizer (referred to as the “CLIE handheld” in this manual).

Your CLIE handheld comes with three manuals:

Read This First

Read This First gives an overview of your CLIE handheld’s features, hardware and software setup, installation instructions, and other important details. Before reading the rest of the manuals, read the Read This First manual.

Operating Instructions (this manual)

This manual describes all you need to know about how to use your CLIE handheld and the Personal Information Management applications that come with it.

The manual shows you how to:

- Turn your CLIE handheld on and off, reset your CLIE handheld, and enter data, explained in greater detail **(Chapter 1)**
- Use Personal Information Management applications: Date Book, Address Book, To Do List, Memo Pad, Expense, and Calculator **(Chapter 2)**
- Perform a HotSync® operation with your computer **(Chapter 3)**
- Exchange data with another handheld by beaming or via “Memory Stick®” media **(Chapter 4)**
- Personalize your CLIE handheld with your own preferences settings **(Chapter 5)**
- Maintain your CLIE handheld and work with the Troubleshooting guide and other technical information **(Chapter 6)**

Add-on Application Guide

The Add-on Application Guide describes how to install and use the supplied add-on applications which include:

- Audio Player/OpenMG Jukebox/RealJukebox
- PictureGear Pocket/PictureGear 4.3Lite
- gMovie
- MS Autorun

Chapter 1

Basic operations of your Sony CLIE Handheld

This chapter explains how to turn on and off your CLIE handheld, enter data, and perform other basic operations.

Contents


Turning on and off your Sony CLIE Handheld	9
Using the stylus	10
Using the Jog Dial™ navigator	12
Entering data into your Sony CLIE Handheld	13
Using Graffiti® writing to enter data	13
Using the onscreen keyboard	22
Using your computer keyboard	24
Changing the frontlight level	25
Resetting your Sony CLIE Handheld	26
Performing a soft reset	26
Performing a hard reset	27

Turning on and off your Sony CLIE Handheld

Turning on your CLIE handheld

Press the **POWER** button.

Your CLIE handheld is turned on, and the last screen you viewed is displayed.



When you turn on your CLIE handheld for the first time, the Setup screen appears.

Note

If the power is not turned on, make sure that the HOLD switch is not in the protect position.

Turning off your CLIE handheld

Press the **POWER** button again.

The power is turned off. You do not have to save data, quit an application or perform any of the other shutdown procedures that your computer requires.

Note


If you press the **POWER** button and hold it down for two seconds or longer, you can turn the frontlight on the screen on or off.

Using the stylus

With your CLIE handheld, you can use the supplied stylus to enter characters or specify an application you want to run.

Taking out the stylus

The stylus is stored in the holder on the back panel of your CLIE handheld. Pull it out when using your CLIE handheld.




Take out the stylus.

To avoid losing the stylus, always put it back into its holder on your CLIE handheld after use.

Tapping

When you enter characters on the screen keyboard of your CLIE handheld, open an application, or select an item, press lightly on the desired button or icon with the stylus.




Press lightly (tap) on the screen

This action is called “tapping.”

Using the stylus

Dragging

Just as you can drag the mouse to select (and drag) text or move objects on your computer, you can also use the stylus to drag an item on the screen of your CLIE handheld. Press the stylus lightly on the item and move it along the screen surface.



Touch the desired item on the screen with the stylus and move it along the screen surface (drag).

Examples of dragging:

To display data above or below the current viewing area on the screen, use the stylus to drag the slider of any scroll bar.

To select multiple characters or items together, use the stylus to drag along the desired characters or items.

Tip on full-screen dragging

By default, full-screen dragging from the bottom of the writing area to the top of the screen displays the Graffiti® Help on the screen. You can assign the full-screen dragging to another activity. See page 165 for details.

Using the Jog Dial™ navigator

Your CLIE handheld is equipped with a Jog Dial™ navigator, which allows you to perform all major operations without the stylus. You can operate your CLIE handheld using the Jog Dial navigator with just one hand.

The icon of any application that supports Jog Dial navigator operations is marked with the  Jog Dial navigator mark.



For other applications, you can also use the JogAssist function to enable Jog Dial navigator operations. For details, see “Changing the Jog Dial™ navigator preferences” on page 167.

Rotating the Jog Dial navigator

Rotate the Jog Dial navigator to select various items in succession or to select an application to start.

The operations you can perform by rotating the Jog Dial navigator differ depending on the application you are using. For details, refer to the instructions for each application.



Pressing the Jog Dial navigator

Press the Jog Dial navigator to highlight the item selected by rotating the Jog Dial navigator, or to run the selected application.

The operations you can do by pressing the Jog Dial navigator differ depending on the application you are using. For details, refer to the instructions for each application.



Rotating while holding down the Jog Dial navigator

Some applications support operations executed by rotating and pressing the Jog Dial navigator. For details, refer to the instructions for each application.

Entering data into your Sony CLIE Handheld

Using Graffiti® writing to enter data

This section explains the procedures for creating letters, numbers, punctuation, and symbols, as well as teaching you some Graffiti® tips and tricks.

What is Graffiti writing?

Most people find they can enter text quickly and accurately with only minutes of practice. Graffiti writing includes any character you can type on a standard keyboard. The Graffiti strokes closely resemble the upper case letters of the regular alphabet, which makes Graffiti writing easy to learn.

There are four basic concepts for success with Graffiti writing:

- If you draw the character shape exactly as shown in the tables later in this chapter (like the shapes shown in the following diagram), you can achieve 100% accuracy.




Graffiti writing examples:
A, B, C, D, and E

- The heavy dot on each shape shows where to begin the stroke. Certain characters have similar shapes, but different beginning and end points. Always begin the stroke at the heavy dot (you should not create the heavy dot; it is only there to show you where to begin the stroke).
- Most characters require only a single stroke. When you lift the stylus from the Graffiti writing area, your CLIE handheld recognizes and displays the text character immediately.

To allow you to write an entire character with a single stroke, some Graffiti strokes are portions of the regular alphabet equivalents.

- The Graffiti writing area is divided into two parts: one for writing the letters of the alphabet and one for writing numbers. The small marks at the top and bottom of the Graffiti writing area separate the two areas.



Entering data in your Sony CLIE Handheld

Writing Graffiti letters

- 1 Tap where you want your text to go.


Note

You need to tap above the Graffiti writing area, and you must see a flashing cursor before you write the text.

- 2 Use the tables on the following pages to find the stroke shape for the letter you want to create. For example, the stroke shown below creates the letter "n".


Note

There are two different stroke shapes available for some letters. For these letters, choose the one that's easiest for you.



As you will see later, you use the same shape to create both the upper case and lower case version of a letter.

- 3 Position the stylus in the left-hand side of the Graffiti writing area.



- 4 Start your stroke at the heavy dot and draw the stroke shape as it appears in the tables.

- 5 Lift the stylus from the screen at the end of the stroke shape.

That is all there is to it. When you lift the stylus from the screen, your CLIE handheld recognizes your stroke immediately and prints the letter at the insertion point on the screen.

As soon as you lift the stylus from the screen, you can begin the stroke for the next character you want to write.

Continued on next page

Entering data in your Sony CLIE Handheld

Note

You must begin the character strokes in the Graffiti writing area. If you do not make Graffiti strokes in the Graffiti writing area, your CLIE handheld does not recognize them as text characters.

Tips on Graffiti writing

- Accuracy improves when you write large characters, You should draw strokes that nearly fill the Graffiti writing area.
- To delete characters, simply set the insertion point to the right of the character you want to delete and make the backspace stroke (a line from right to left) in the Graffiti writing area.
- Write at natural speed. Writing too slowly can generate recognition errors.
- Do not write on a slant. Vertical strokes should be parallel to the sides of the Graffiti writing area.
- Press firmly.

To display the Graffiti onscreen help

Drag the stylus from the bottom of the writing area to the top of the screen. Graffiti Help opens a series of screens that show the complete Graffiti character set.

Entering data in your Sony CLIE Handheld

Writing Graffiti alphabet

Draw Graffiti letters according to the following alphabet in the left-hand side of the Graffiti writing area.

A		N	
B		O	
C		P	
D		Q	
E		R	
F		S	
G		T	
H		U	
I		V	
J		W	
K		X	
L		Y	
M		Z	
Space		BackSpace	
CarriageReturn		Period	Tap twice


Entering data in your Sony CLIE Handheld

To write capital letters

Shift to caps and then you can make capital letters with the same stroke shapes as the basic alphabet characters.

■ To draw the first letter of a word as a capital letter

Use the Caps Shift stroke ↓.




To return to the lower case, use the Backspace stroke ____.

Note

When you create a new sentence or a new record (by tapping New or a blank line), the first letter is automatically capitalized.

■ To enter only capital letters (Caps Lock)

Use the Caps Lock stroke ↓↓.



To return to the lower case, use the CapsShift stroke ↓.

Writing numbers


Write the following numbers on the right-hand side (numbers side) of the Graffiti writing area.

0		5	
1		6	
2		7	
3		8	
4		9	

Entering data in your Sony CLIE Handheld

Writing punctuation marks

Make a single tap on the Graffiti writing area to activate Punctuation Shift. The next stroke you make anywhere in the Graffiti area (the letters or numbers side) creates a punctuation mark.




(.) Period	•	(—) Dash	—
(,) Comma	,	(() Left Paren	(
(') Apostrophe	'	() Right Paren)
(?) Question	?	(/) Slash	/
(!) Exclamation	!	(\$) Dollar	\$
(@) At	@	(\) Back slash	\
(#) Number	#	({) Left brace	{
(%) Percent	%	(}) Right brace	}
(^) Circumflex	^	([) Left square bracket	[
(&) Ampersand	&	(]) Right square bracket]
(*) Asterisk	*	(~) Swung dash	~
(<) Left angle bracket	<	(`) Grave accent	`
(>) Right angle bracket	>	(;) Semicolon	;
(_) Under bar	_	(:) Colon	:
(") Ditto	"	Tab	↵

Entering data in your Sony CLIE Handheld

Writing symbols and extended characters

Make a Symbol Shift stroke  on the Graffiti writing area to activate Symbol Shift. The next stroke you make creates a symbol or extended character.



(•) Bullet	•	x	
(™) Trademark	™	÷	
(®) Registered	®	=	
(©) Copyrighted	©	(¢) Cent	¢
(') Left single quotation	'	(¥) Yen	¥
(') Right single quotation	'	(£) Pound	£
(") Left double quotation	"	ι	ι
") Right double quotation	"	i	i
(§) Section	§	β	β
(°) Degree	°	μ	μ
+	+	f	f
±	±	ø	ø

Entering data in your Sony CLIE Handheld

Writing accented characters and non-English characters

To create accented characters, draw the stroke normally used to create the letter, followed by an accent stroke. Graffiti writing then adds the accent to the letter.

To enter “é,” for example, draw  and then .

à è ì ò ù



á é í ó ú ý



â ê î ô û



ã õ ñ



ä ï ö ü ÿ



å



To write non-English characters

You can write the following characters without any special punctuation or shifting:

ç



æ



Note

You must write these non-English characters on the left side of the Graffiti writing area.

Entering data in your CLIE handheld

Using Navigation strokes

In addition to character symbols, Graffiti writing includes special strokes that you can use to navigate within text or fields in your applications.

Move cursor right	
Move cursor left	
Go to the previous field (Address Book only)	
Go to the next field (Address Book only)	
Open Address Record (Address Book only)	

Using Graffiti ShortCuts

Graffiti ShortCuts, similar to the glossary or autotext features of some word processors, allow you to enter commonly used words or phrases quickly and easily. In addition to the following predefined ShortCuts, you can create your own ShortCuts for your name or the header of a memo (page 176). Each ShortCut can represent up to 45 characters.

To use a ShortCut, draw the ShortCut stroke  followed by the ShortCut characters. When you draw the ShortCut stroke, the ShortCut symbol appears at the insertion point to show that you are in ShortCut mode. When you enter  and dts (, , and ) , you can enter date and time stamps.

Data stamp	ds	Breakfast	br
Time stamp	ts	Lunch	lu
Date/time stamps	dts	Dinner	di
Meeting	me		


Entering data in your Sony CLIE Handheld

Using the onscreen keyboard

You can open the onscreen keyboard any time you need to enter text or numbers into your CLIE handheld. Note that you cannot enter Graffiti characters while using the onscreen keyboard.


To use the onscreen keyboard:

- 1** Open any application (such as Memo Pad).
- 2** Tap any record, or tap New.





- 3** Tap "a" to open the alphabetic keyboard, or tap "1" to open the numeric keyboard.

The selected keyboard is displayed.



Continued on next page


Entering data in your Sony CLIE Handheld



4 Select the desired keyboard and tap the characters to enter text and numbers.

You can use the online keyboard in the same way as in the keyboard of your computer. To enter capital letter, tap cap and then tap the character button. To delete a character, tap ←.

5 After you finish, tap Done to close the onscreen keyboard and place the text in the record.



Entering data in your Sony CLIE Handheld

Using your computer keyboard

If you have a lot of data to enter, or prefer to use the computer keyboard, you can use Palm™ Desktop for CLIE software or any other supported personal information manager (PIM), such as Microsoft Outlook®, to enter information. You can then perform a HotSync® operation to synchronize the information on your computer with the information on your CLIE handheld. All the main applications on your CLIE handheld are also available in Palm Desktop for CLIE software and in most PIMs, so you don't need to learn different applications.

Refer to the Palm Desktop for CLIE software online Help for more information on entering data on your computer.

To import data from your computer or another handheld

If you have data stored in computer applications such as spreadsheets, databases, or if you want to import data from another handheld, you can transfer the data to your CLIE handheld and use it without entering data manually. Save the data in a compatible file format (.csv, .txt, .tab, .tsv, .dba, .aba, .tda, .mpa), import it into your Palm Desktop for Sony software, and then perform a HotSync operation to transfer the data to your CLIE handheld. For details, see “Chapter 3: Exchanging and updating data using a HotSync® operation.”

Changing the frontlight level

You can turn the frontlight on the screen off or on or adjust the frontlight level according to the lighting conditions or temperature of the environment where you use your CLIE handheld.

Turning the frontlight off and on

Press and hold down the POWER button for more than two seconds to turn the frontlight off or on.

Adjusting the frontlight level

Even with the frontlight on, you may need to further adjust the brightness on the screen.

You can use the onscreen brightness control to adjust the frontlight level.

1 Tap .



Tap this icon.

The adjustment control screen is displayed.

2 To change the level in small increments, tap to the left or right.

To change the brightness level in larger increments, drag the slider to the left or right.

Tip

You can also press the scroll button to move the slider incrementally.

3 Tap Done.

Resetting your Sony CLIE Handheld


Under normal circumstances, you will not have to reset your CLIE handheld.

On rare occasions, however, your CLIE handheld may no longer respond to buttons or the screen due to insufficient memory or other reasons. In this case, you need to perform a reset to get your CLIE handheld running again.


Performing a soft reset

A soft reset tells your CLIE handheld to stop what it's doing and start over again. All records and entries stored in your CLIE handheld are retained with a soft reset.

- 1** Take out the reset tip by unscrewing the metal barrel from the stylus quill.



- 2** Use the reset tip to gently press the reset button inside the hole on the back panel of your CLIE handheld.



The system shuts down and then restarts.

After restarting, the system displays "Palm Computing Platform," "CLIE," and "Sony," followed by the preferences screen for setting the time and date.

Resetting your Sony CLIE Handheld

Performing a hard reset


If the soft reset does not solve the problem, you need to perform a hard reset to restart your CLIE handheld.

Note

With a hard reset, all records and entries stored in your CLIE handheld are erased. Only perform a hard reset if a soft reset does not solve your problem.

If you save a backup of your CLIE handheld data on your computer, you can restore any data previously synchronized with your computer during the next HotSync® operation.

- 1** Hold down the POWER button on your CLIE handheld.
- 2** While holding down the POWER button, use the reset tip to gently press and release the reset button.



The Palm Computing Platform window is displayed

- 3** Release the POWER button.
A message warning that you are about to erase all the data stored on your CLIE handheld is displayed.
- 4** Press the upper half of the scroll button on the front panel of your CLIE handheld.
Your CLIE handheld undergoes a hard reset.
After a hard reset, only the current data and time are retained. Formats, Preferences, and other settings are restored to their factory default settings.

Note

If the scroll button was used just prior to hard-resetting, the hard-reset may not be performed.

Chapter 2

Using basic applications

This chapter describes how to do tasks that are specific or common to the basic applications of your CLIE handheld: Date Book, Address Book, To Do List, Memo Pad, Expense, and Calculator.

Contents

 Managing schedules and events (Date Book)	29
 Managing addresses and phone numbers (Address Book)	49
 Managing tasks and things to do (To Do List)	63
 Creating memos (Memo Pad)	71
 Managing expenses (Expense)	79
 Using Calculator (Calc)	89
Performing common tasks	91
Using the Application Launcher	91
Categorizing records	95
Finding records	98
Protecting your data (Security)	102
Attaching notes	108
Purging records	109
Using the Edit menu	110
Choosing fonts	111



Managing schedules and events (Date Book)

Date Book lets you quickly and easily schedule appointments or any activity associated with a date or a date and time. A record in Date Book is called an “event.”

Note

If the HOLD switch is in the protect position, you cannot operate your CLIE handheld.

Scheduling an event

Scheduling an event for the current date


- 1 Press the Date Book  button on the front panel.

Date Book starts up. Today’s schedule is displayed with a list of times for a standard business day.

Tip

Press the Date Book button repeatedly to cycle through the Day, Week, Month, and Agenda views. The Date Book views are displayed at the bottom left of the screen.

- 2 Tap the time line that corresponds to the beginning of the event.




Continued on next page



Managing schedules and events (Date Book)

3 Enter a description of the event.


You can enter a description or note up to 255 characters in length.



4 If the event is one hour long, skip to Step 7. If the event is longer or shorter than one hour, tap the time of the event to open the Set Time dialog box.

5 Do one of the following to set the duration of the event:

- Tap the time columns on the right side of the Set Time dialog box to set the Start Time, and tap the End Time box. Then tap the time columns to set the End Time.
- Tap All Day to automatically insert the start and end time of the event as defined in your Date Book preferences.



6 Tap OK.

7 Tap a blank area of the screen to deselect the event.

A vertical line appears next to the time, indicating the duration of the event.

Continued on next page



Managing schedules and events (Date Book)

Tip

You can open the Set Time dialog box (to select a start time) by writing a number on the number side of the Graffiti writing area and making sure no event is selected.

To schedule an untimed event

In step 5, tap No Time. A new untimed event is displayed in the first line in Date Book with a ♦ mark.

Scheduling a timed event for another date

- 1 Press the Date Book  button on the front panel.


Date Book starts up.

- 2 Do one of the following to select the date you want for the event:

- Tap the day of the week on top of the Date Book screen.
To move to another week, tap one of the scroll arrows of either side of the day of the week area.



- Tap Go to at the bottom of the screen.
The Go to Date dialog box appears. Select a date by tapping a year, month, and day in the calendar.



- 3 Follow the steps for "Scheduling an event for the current date."

Continued on next page



Managing schedules and events (Date Book)

Tip

You can also use the scroll button on the front panel to move forward or backward one day or one month at a time.

To schedule an untimed event

In step 3, tap New and then tap No Time. Then follow the steps for “Scheduling an event for the current date.”

Tip

You can create a new untimed event by making sure no event is selected and then writing letters in the Graffiti writing area. When you start writing, the untimed event appears at the top of the screen.

Scheduling repeating or continuous events

The Repeat function lets you schedule events that recur at regular intervals or extend over a period of consecutive days.

Examples of repeating or continuous events

- Birthday: an event that repeats annually
- Weekly guitar lesson: an event that falls on the same day of the week and the same time of day
- Business trip or vacation: a continuous event


1 Press the Date Book  button on the front panel.

Date Book starts up.

2 Tap the description of the event.

3 Tap Details.

The Event Details dialog box appears.



The Event Details dialog box is shown with the following fields and options:

- Time:** 9:00 am - 10:00 am
- Date:** Mon 5/7/01
- Alarm:**
- Repeat:** None
- Private:**

Buttons at the bottom: OK, Cancel, Delete..., Note

Continued on next page



Managing schedules and events (Date Book)

4 Tap Repeat.

The Change Repeat dialog box appears.

The dialog box is titled "Change Repeat" and has an information icon in the top right corner. It features a horizontal row of five buttons: "None", "Day", "Week", "Month", and "Year". Below this row, the text reads: "Tap one of the above buttons to set a repeat interval." Underneath the text is a large rectangular text area containing the text "No Repeat". At the bottom of the dialog are two buttons: "OK" and "Cancel".

5 Tap Day, Week, Month, or Year to set how often the event repeats.

For a continuous event, tap Day.

The dialog box is titled "Change Repeat" and has an information icon in the top right corner. The "Day" button is now selected and highlighted. Below the buttons, the text reads: "Every: 1 Day(s)". Underneath this, it says "End on: No End Date" with a small downward arrow to the left. Below the text is a large rectangular text area containing the text "Every day". At the bottom of the dialog are two buttons: "OK" and "Cancel".

6 Enter a number that corresponds to how often you want the event to repeat on the Every line.

- When you tap Week: Tap a letter representing each day of the week on Repeat on line to specify the day you want the event to repeat.

The dialog box is titled "Change Repeat" and has an information icon in the top right corner. The "Week" button is now selected and highlighted. Below the buttons, the text reads: "Every: 3 Week(s)". Underneath this, it says "End on: No End Date" with a small downward arrow to the left. Below the text is a "Repeat on:" label followed by a row of seven buttons: "S", "M", "T", "W", "T", "F", and "S". The "S" and "W" buttons are highlighted. Below the buttons is a large rectangular text area containing the text "Every 3rd week on Sun and Wed". At the bottom of the dialog are two buttons: "OK" and "Cancel".

Continued on next page



Managing schedules and events (Date Book)

- When you tap Month: On the Repeat by line, tap Day to repeat the event on the specified day of the same week each month, or tap Date to repeat the event on the specified date each month.




The dialog box is titled "Change Repeat" and contains the following elements:

- Repeat frequency: None | Day | Week | Month | Year (Month is selected)
- Every: 3 Month(s)
- End on: No End Date (with a dropdown arrow)
- Repeat by: Day | Date (Day is selected)
- Summary text: "The 1st Monday of every 3rd month"
- Buttons: OK, Cancel

- 7 To specify an end date for the repeating or continuous event, tap the arrow ▼ next to End on to display the drop-down list and then tap Choose Date.

The Ending On screen appears.



The "Ending On" screen shows a calendar for the year 2001. The month of May is highlighted. The date 7 is selected. The screen includes navigation arrows for the year, a grid of months, a grid of days, and "Cancel" and "Today" buttons.

Ending On						
◀ 2001 ▶						
Jan	Feb	Mar	Apr	May	Jun	
Jul	Aug	Sep	Oct	Nov	Dec	
S	M	T	W	T	F	S
		1	2	3	4	5
6	7	8	9	10	11	12
13	14	15	16	17	18	19
20	21	22	23	24	25	26
27	28	29	30	31		

- 8 Tap the end date on the screen.
The Change Repeat screen appears again.
- 9 Tap OK.
The Event Details screen appears again.

Continued on next page




Managing schedules and events (Date Book)

10 Tap OK.

The Date Book screen is displayed again.

Make sure that the repeat  icon is displayed to the far right of the event.



Notes

- If you change the start date of a repeating event, your CLIE handheld calculates the number of days you moved the event. Your CLIE handheld then automatically changes the end date to maintain the duration of the repeating event.
- If you change the repeat interval (e.g., daily to weekly) of a repeating event, past occurrences (prior to the day on which you change the setting) are not changed, and your CLIE handheld creates a new repeating event.
- If you change the date of an occurrence of a repeating event (e.g., from January 14 to January 15) and apply the change to all occurrences, the new date becomes the start date of the repeating event. Your CLIE handheld adjusts the end date to maintain the duration of the event.
- If you change other repeat settings (e.g., time, alarm, private) of a repeating event and apply the change to all occurrences, your CLIE handheld creates a new event. The start date of this new event is the day on which the setting is changed. Past occurrences (prior to the day of the change) are not changed.
- If you apply a change to a single occurrence of a repeating event (e.g., time), that occurrence no longer shows the repeat  icon.



Managing schedules and events (Date Book)

Checking schedules

Displaying the Day view

You can display and check the events for a specific day.

- 1 Press the Date Book  button on the front panel.
Date Book starts. Today's schedule is displayed.
- 2 Rotate the Jog Dial™ navigator to display the events for yesterday or tomorrow.
You can display the schedule for a specific day and time.


To change the Date Book view

In addition to displaying the time list for a specific day, you can also display a whole week, a month, or an agenda.

To display the next view, press the Jog Dial navigator repeatedly.

Tip

You can also select the Date Book view by tapping an icon on the Date Book screen. Tap one of the following icons to rotate to the corresponding calendar view:



Tap the desired view icon.

-  : Day view
-  : Week view
-  : Month view
-  : Agenda view



Managing schedules and events (Date Book)

Displaying the Week view


Week view displays a calendar of your events for an entire week. This view lets you quickly review your appointments and available time slots. In addition, the graphical display helps you spot overlaps and conflicts in your schedule.

- 1 Press Date Book  button on the front panel.

Date Book starts up.

- 2 Press the Jog Dial navigator repeatedly or tap the  Week view icon.


The Week view appears. This screen shows untimed events or available time slots.



- 3 Rotate the Jog Dial navigator to select the day that you want to review.

- 4 Press the Jog Dial navigator.

The details of the selected event are displayed.



Continued on next page




Managing schedules and events (Date Book)

Tips for using the Week view

- To reschedule an event while in the Week view, tap and drag the event to a different time or day.
- Tap a blank time on any day to move to that day and have the time selected for a new event.
- Tap any day or date that appears at the top of the Week view to move directly to that day without selecting an event.
- The Week view displays the time span defined by the Start Time and End Time in the Date Book Preferences settings. If you have an event before or after this time span, a bar appears at the top or bottom of that day's column. Use the onscreen scroll arrows  to scroll to the event.

To spot event conflicts

An event conflict (time overlap) appears in the Week view as overlapping time bars and in the Day view as overlapping brackets to the left of the conflicting times.





Managing schedules and events (Date Book)

Displaying the Month view

The Month view screen shows which days have events scheduled. Dots and lines in the Month view indicate events, repeating events, and untimed events.

- 1 Press the Date Book  button on the front panel.

Date Book starts up.

- 2 Press the Jog Dial navigator repeatedly or tap the  Month view icon.

The Month view screen appears.



May 2001							◀ ▶	
S	M	T	W	T	F	S		
		1	2	3	4	5		
6	7	8	9	10	11	12		
13	14	15	16	17	18	19		
20	21	22	23	24	25	26		
27	28	29	30	31				
. ...  (Go to)								

- 3 Rotate the Jog Dial navigator to select the day that you want to review.

To select the next day, rotate the Jog Dial navigator.

- 4 Press the Jog Dial navigator.

The details of the selected day are displayed.

Tips for using the Month view

- Tap a day in the Month view to display that day in the Day view.
- Tap the scroll arrows  in the upper right corner to move forward or backward a month.
- Tap Go to to open the Go to Date dialog box to select a different month.
- Use the scroll buttons on the front panel of your CLIE handheld to move between months. Press the upper half of the scroll button to display the previous month, the lower half of the scroll button to display the next month.



Managing schedules and events (Date Book)


Displaying the Agenda view

The Agenda view shows you your appointments, untimed events, and To Do List items in a single screen. As well as checking the detailed information on an event, you can also use the Agenda view to check off completed To Do List items.

- 1 Press the Date Book  button on the front panel.
Date Book starts up.

- 2 Press the Jog Dial navigator repeatedly or tap the  Agenda view icon.

The Agenda view screen appears. Today's schedule and To Do List is displayed.



- 3 Rotate the Jog Dial navigator to select the day that you want to review.

To select the next day, rotate the Jog Dial navigator.

Tips for using Agenda view


- Tap any appointment while in Agenda view to display the Day view of the appointment.
- Check off completed To Do List items in the Agenda view, or tap a description of an item to go directly into the To Do List application.



Managing schedules and events (Date Book)

Changing Date and Time view

Tap and hold the date in the title bar of Date Book.
The current time appears.



When you release the stylus, the menu bar appears. If you want to avoid displaying the menu when releasing the stylus, drag the stylus away from the date indication after the current time appears.




Editing Date Book events

Changing a date or time for an event

1 On the Date Book screen, tap the event you want to edit.

2 Tap Details.

The Event Details dialog box appears.



The image shows a screenshot of the 'Event Details' dialog box. It has a title bar with 'Event Details' and an information icon. The fields are: Time: 4:00 pm - 5:00 pm, Date: Wed 5/16/01, Alarm: , Repeat: None, Private: . At the bottom are buttons for OK, Cancel, Delete..., and Note.

3 • To change the time, tap the Time box and select a new time.

The Set Time dialog box appears. Tap the Set Time and the End Time.

• To change the date, tap the Date box and select a new date.

The Set Date dialog box appears. Specify the year, month, and day in the calendar.

4 Tap OK.



Managing schedules and events (Date Book)

Changing a timed event to an untimed event

- 1 On the Date Book screen, tap the event you want to edit.
- 2 Tap Details.
- 3 Tap the Time box.
The Set Time screen appears.
- 4 Tap No Time and then tap OK.
The Event Details screen appears.



The Event Details dialog box is shown with the following fields and options:

- Time: No time
- Date: Wed 5/18/01
- Alarm:
- Repeat: None
- Private:
- Buttons: OK, Cancel, Delete..., Note

- 5 Tap OK.

The untimed event is displayed in the first line with the untimed ♦ mark.



The Date Book screen for May 16, 01 shows a calendar grid with the following event:

- Meeting at the show room (marked with a ♦)
- Sales meeting (marked with a |)

Buttons at the bottom: (New) (Details) (Go to)



Managing schedules and events (Date Book)

Setting an alarm for an event

The Alarm setting enables you to set an audible alarm for events in your Date Book. You can set an alarm to sound minutes, hours, or days before an event. The default Alarm setting is 5 minutes before the time of the event, but you can change this to any number of minutes, hours, or days.

When you set an alarm, an alarm  icon appears to the far right of the event with the alarm.


1 On the Date Book screen, tap the event to which you want to assign an alarm.

2 Tap Details.

The Event Details dialog box appears.

3 Tap the Alarm check box to select it.

The alarm is set.



The image shows a screenshot of the 'Event Details' dialog box. It has a title bar with 'Event Details' and an information icon. The fields are: Time: 12:00 pm - 1:00 pm; Date: Wed 5/16/01; Alarm: checked checkbox followed by a dropdown menu showing '5' and 'Minutes'; Repeat: None; Private: unchecked checkbox. At the bottom are four buttons: OK, Cancel, Delete..., and Note.

4 Tap the arrow ▼ to select the time unit from among Minutes, Hours, or Days.

5 Tap the "5" next to the Alarm check box and enter any number from 0 to 99 as the number of time units.

6 Tap OK.

Continued on next page



Managing schedules and events (Date Book)

Setting an alarm for an untimed event

You can set a silent alarm for an untimed event. In this case, the alarm triggers at the specified period of minutes, hours, or days before midnight (beginning) of the day of the untimed event. No audible alarm sounds for an untimed event. The reminder message appears onscreen instead.

Example: When you set an alarm for an untimed event that occurs on February 4 and if the alarm is set for 5 minutes, the reminder message appears at 11:55 PM on the night of February 3. The reminder remains onscreen until you turn on your handheld and tap OK to erase it.

Making an event private

You can hide records that you mark as private. If you define a password for your CLIE handheld, you must enter it to display private records.

1 On the Date Book screen, tap the event you want to mark as private.

2 Tap Details.

The Event Details dialog box appears.

3 Tap the Private check box.

Event Details

Time: 12:00 pm - 1:00 pm

Date: Wed 5/16/01

Alarm:

Repeat: None

Private:

OK Cancel Delete... Note

4 Tap OK.

The event is marked as private. For hiding or masking private events, see “Protecting your data (Security)” on page 102.



Managing schedules and events (Date Book)

Deleting events

You can delete existing events in Date Book.

Note

If you delete the contents of a repeating event, all the related events will be deleted. When deleting an event in Delete Event dialog box, you can delete a single event as an exception or all the related events.

- 1** On the Date Book screen, tap the event you want to delete.
- 2** Tap Details.
- 3** Tap Delete.
The Delete Event dialog box appears.
- 4** Tap OK to delete the event.
The selected event is deleted. To cancel deletion, tap Cancel.

Tip

If you select the “Save archive copy on PC” check box, the deleted date will be saved onto the Palm™ Desktop for CLIE software on your computer during the next HotSync® operation.



Managing schedules and events (Date Book)

Using the Date Book menus

This section explains the menu commands specific to Date Book. For the Edit menu, see “Using the Edit menu” on page 110.

Record menus

New Event	Creates a new event. The Set Time dialog box for selecting the start and end times is displayed.
Delete Event	Deletes the currently selected event. The Delete Event dialog box appears.
Attach Note	Attaches notes to the current event. This menu opens up a dialog box for entering comments.
Delete Note	Deletes notes from the current event. The Delete Note dialog box is displayed.
Purge	<p>You can specify a certain period based on the current date and discard any events that were formed before the specified date. Use this function to save memory space.</p> <p>Notes</p> <ul style="list-style-type: none">• A repeating event will not be deleted.• By default, the events that you purge are restored and saved in the Palm Desktop for CLIE software on your computer at the next HotSync operation. To delete the events completely, deselect the check box (<input type="checkbox"/>) for “Save archive copy on PC” in the Purge dialog box .
Beam Event	Sends the current event to another CLIE handheld via the infrared communications port.



Managing schedules and events (Date Book)

Options menus

Font	You can select a desired font in the Select Font dialog box.
Preferences	<ul style="list-style-type: none">• Start/End Time: Defines the start and end times for Date Book screens. If the time slots you select do not fit on one screen, you can tap the scroll arrows  to scroll up and down.• Alarm Preset: Automatically sets an alarm for each new event. The silent alarm for untimed events is defined by minutes, days, or hours before midnight of the date of the event.• Alarm Sound: Sets the tone of the alarm.• Remind Me: Defines how many times the alarm sounds. The choices are Once, Twice, 3 Times, 5 Times, and 10 Times.• Play Every: Defines how often the alarm sounds. The choices are Minute, 5 minutes, 10 minutes, and 30 minutes.
Display Options	<p>Changes the Date Book's appearance and which events display.</p> <ul style="list-style-type: none">• Show Time Bars: Activates the time bars that appear in the Day view. The time bars show the duration of an event and illustrates event conflicts.• Compress Day View: Controls how times appear in the Day view. When Compress Day view is off, all time slots are displayed. When it is on, start and end times display for each event, but blank time slots toward the bottom of the screen disappear to minimize scrolling.• Month View settings: These check boxes apply to the Month view of Date Book. You can activate any or all of these settings to show that you have Timed, Untimed, or Daily Repeating events in the Month view only.
Phone Lookup	The Phone Number Lookup screen appears. If there is an Address Book entry, you can look up the phone number of the selected item.
Security	Hides the current item unless the password is entered. You can select the view option among Show Records, Mask Records, or Hide Records.
About Date Book	Shows version information for Date Book.



Managing addresses and phone numbers (Address Book)

Address Book lets you keep names, addresses, telephone numbers, and other information about your personal or business contacts. An item in Address Book is called an “entry.”

Note

If the HOLD switch is in the protect position, you cannot operate your CLIE handheld.


Creating a new Address Book entry

- 1 Press the Address Book button on the front panel. The Address screen is displayed.

Note

Press the Address Book button repeatedly to cycle through the categories in which you have entries.

- 2 Tap New. The Address Edit screen appears.



- 3 Enter the last name of the person you want to add to Address Book.

The first letter of each field (except numeric and e-mail fields) is automatically capitalized.

- 4 Tap First name.

The cursor shifts to the first name field.

You can also use the Graffiti software to move the cursor to the next field by entering .

Continued on next page



Managing addresses and phone numbers (Address Book)

5 Enter the first name in the First name field.

Address Edit Unfiled

No Image

Last name: **Carter**

First name: **Melanie**

Title:

Company:

▼ Work:

▼ Home:

Done Details... Note

6 Repeat steps 4 and 5 to enter the other items of information that you want to include.

You can tap the scroll arrow ▼ next to each item to display the list of choices and then tap the desired item in the list.

7 To move to the next page of information, tap the scroll arrow ▼ on the bottom-right corner of the screen.

8 After you finish entering all the necessary information, tap Done.

The Address screen is displayed again.

Address All

Carter, Mela ###-###-###...W

Look Up New

Tip


You can also use the Palm™ Desktop software to create entries on your computer and then download them to your CLIE handheld with your next HotSync® operation. See “Performing a local HotSync® operation with the cradle” on page 114 for details.



Managing addresses and phone numbers (Address Book)

Viewing Address Book entries

- 1** Press the Address Book  button on the front panel.
The Address screen is displayed, listing your current entries.
- 2** Rotate the Jog Dial™ navigator to select the address record you want to view.
If the desired address record is not displayed, rotate the Jog Dial navigator further to scroll up or down the entire list.
- 3** Press the Jog Dial navigator.
The Address View screen of the selected record is displayed.



- 4** To return to the list of address entries, press the Jog Dial navigator again or press BACK.
The Address screen is displayed again.

Tips on navigating among your address entries

- If there are multiple pages of information, the scroll button moves up or down an address list or the Address View screen. If you hold down the scroll button, you accelerate the scrolling and display every third screen.
- You can also use the stylus to tap the onscreen scroll arrows  to scroll to the entry.

To view an image pasted to an address record

Tap an image on the Address View screen. The image is displayed across the whole screen. To return the Address View screen, tap the image again.

To view the next page of the Address View screen

Rotate the Jog Dial navigator On the Address View screen. The next or previous page within the data is displayed.



Viewing addresses by category

Press the Jog Dial navigator when the address list is displayed but none of the listed entries are selected.

Each time you press the Jog Dial navigator, the display toggles through all the available categories.

Tip on selecting the desired category from the categories list

Tap the arrow ▼ at the upper right corner of the screen to display the category list. You can select the desired category from the list.





Managing addresses and phone numbers (Address Book)

Sorting the address entries in the list

You can sort the address entries in your desired order: listing by last and then first name, or listing by company and then last name. The address entries will be displayed in the selected order when you start Address Book. Any changes in the address order, however, do not affect the original address entries.


1 Press the Address Book  button on the front panel.
The Address screen is displayed, listing your current entries.

2 Tap the Menu  icon.

Address Book menu is displayed.

3 Tap Options, and then tap Preferences.

The Address Book Preferences dialog box appears.



The dialog box titled "Address Book Preferences" contains the following elements:

- A checkbox labeled "Remember last category" which is currently unchecked.
- A section labeled "List By:" with two selectable options:
 - "Last Name, First Name" (highlighted with a dark background)
 - "Company, Last Name"
- Two buttons at the bottom: "OK" and "Cancel".

4 Tap the desired order of the address entries in the List By field.
Select the desired order that the address entries are to be listed when Address Book starts.

5 Tap OK.

The address entries are sorted in the selected order.

Notes

- When you tap Last Name, First Name, the address entries are sorted in alphabetical order of an individual's last name and then first name.
- When you tap Company, Last Name, the address entries are sorted in alphabetical order of the company name, and then an individual's last name.



Managing addresses and phone numbers (Address Book)


Looking up an address record

The Look Up feature helps you to quickly scroll to any of your address entries.

- 1 On the Address Book list screen, enter the first letter of the entry you want to find.

The list scrolls to the first entry that begins with that letter. If you write another letter, the list scrolls to the first entry that starts with those two letters.

For example, writing an “s” scrolls to “Sands,” and writing “sm” scrolls further to “Smith.” If you sort the list by company name, the Look Up feature scrolls to the first letter of the company name.



- 2 Tap the entry you want to view or press the Jog Dial navigator.

The entry you selected is shown.



Editing Address Book entries

Pasting an image to an address record

You can paste an image to the address information. Paste a photograph of a person or restaurant, for example, as a reminder of an address record.

To paste an image, install the PictureGear™ Pocket software onto your CLIE handheld. For installation, see “Installing add-on applications onto your Sony CLIE Handheld” in the Read This First manual.


- 1 Tap the address record to which you want to paste an image in the address list.

The Address View screen of the selected address record appears.


- 2 Tap Edit.

The Address Edit screen appears.

- 3 Tap No Image in the upper right of the screen.



The PG Pocket screen appears.



Continued on next page



4 Tap the image you want to paste.

The image you selected is pasted to the address information.

5 Tap Done.

The Address screen is displayed again.

A camera  icon is attached to the record that has the pasted image.

Note

If you use the Palm Desktop software to change the category of the address record that has a pasted image, the image will no longer be associated with the address record after the next HotSync operation. To edit an address record with a pasted image, use the Address Book application in your CLIE handheld.

To change the image

Tap the Menu  icon and select Another Image. Perform steps 4 and 5.

To remove the image

Tap the Menu  icon and select No Image.



Modifying an address record

You can modify part of the address record.

- 1 On the Address Book list screen, tap the entry you want to modify.

The Address View screen of the selected record appears.

- 2 Tap Edit.

The Address Edit screen appears.

- 3 Tap the field that you want to edit.

You can edit the tapped field.

- 4 Edit the entry.

- 5 When modification is complete, tap Done.

The Address screen is displayed again.

To select types of phone numbers

You can select the types of phone numbers or e-mail addresses that you associate with an Address Book record. Any changes you make apply only to the current entry. To select other types of phone numbers in an entry, tap the arrow ▼ and select the desired label from the drop-down list.





Managing addresses and phone numbers (Address Book)

Duplicating an address record

You can copy existing address entries you have created. This feature is useful when you use the address of one person or edit part of the address for another person.

- 1 On the Address Book list screen, tap the entry you want to copy.
The Address View screen of the selected record appears.
- 2 Tap the Address View title bar.
The Address Book menu is displayed.



- 3 Tap Duplicate Address from the Record menu.
The entry you selected in Step 2 is copied.
The word “Copy” is added to the end of the name field of the copied information.



- 4 Tap Done.
The Address screen is displayed again.

Note

The pasted image is not duplicated.



Deleting an address record

- 1 On the Address Book list screen, tap the entry you want to delete.

The Address View screen of the selected record appears.

- 2 Tap Edit.

The Address Edit screen appears.

- 3 Tap Details.

The Address Entry Details dialog box appears.



- 4 Tap Delete.

The Delete Address dialog box appears.



- 5 Tap OK to delete the entry.

The selected record is deleted. To cancel deletion, tap Cancel.

Tip

If you select the “Save archive copy on PC” check box, the deleted data will be saved onto the Palm Desktop for Sony software on your computer during the next HotSync operation.



Changing the address record details

You can change the type of information that appears in the address list screen, categorize an entry, and hide an entry for security reasons. You can also delete entries.

1 On the Address Book list screen, tap the entry you want to change.
The Address View appears.

2 Tap Edit.
The Address Edit screen appears.

3 Tap Details.
The Address Entry Details dialog box appears.

4 Change desired settings.

Show in List: Select which type of entries or other information appears in the Address list screen. Tap the arrow ▼ and select from Work, Home, Fax, Other, or E-mail.



Category: Assign the entry to a category.



Private: Select the Private check box to hide the current entry when Security is turned on. For details on Security, see “Protecting your data (Security)” on page 102.



5 Tap OK.
The address record details are saved.



Managing addresses and phone numbers (Address Book)

Using the Address Book menus

This section explains the menu commands specific to Address Book. For the Edit menu, see “Using the Edit menu” on page 110. The Record and Options menus differ depending on whether you are displaying the Address List screen or the Address View screen.

Record menus

Duplicate Address	Makes a copy of the current record and displays the copy in Address Edit so you can make changes to the copied record. The copy has the same category and attached notes as the original record.
Beam Address	Sends all the address entries in the currently selected category to another Sony handheld via the infrared communications port.
Beam Business Card	Sends the current business card to another Sony handheld via the infrared communications port. You can also send a business card via the infrared communications port by pressing and holding down the Address Book button for longer than 2 seconds. This menu item is highly useful because you can exchange business cards with other Sony handhelds with ease.
Delete Address	Deletes the current address record. The Delete Address dialog box appears. Note By default, the records that you delete are restored and saved in Palm Desktop for CLIE software on your computer at the next HotSync operation. To delete the records completely, deselect the check box (<input type="checkbox"/>) for “Save archive copy on PC” in the Delete Event dialog box .
Attach Note	Adds comments to the current address record. Choosing this menu opens up a screen for entering comments.
Delete Note	Deletes comments from the current address record. Choosing this menu opens up the Delete Note dialog box. Tap Yes to delete comments and No to cancel the delete function.
Select Business Card	Defines the current address record on a business card.



Managing addresses and phone numbers (Address Book)

Options menus

Font	You can select a desired font in the Select Font dialog box .
Preferences	Remember last category: Determines how Address Book appears when you return to it from another application. If you select this check box, Address Book shows the last category you selected. If you clear it, Address Book displays All category.
Rename Custom Fields	These custom fields appear at the end of the Address Edit screen. Rename them to identify the kind of information you enter in them. The names you give the custom fields appear in all entries.
Security	Hides the current record unless the password is entered. You can select the view option among Show Records, Mask Records, or Hide Records.
About Address Book	Shows the version information for Address Book.



Managing tasks and things to do (To Do List)

A To Do List is a reminder of some task you have to complete. A record in To Do List is called an “item.”

Note

If the HOLD switch is in the protect position, you cannot operate your CLIE handheld.


Creating To Do List items

- 1 Press the To Do List (☰) button on the front panel.
To Do List opens and displays the category of items you last viewed.

Note

Press the To Do List application button repeatedly to cycle through the categories in which you have items.

- 2 Tap New.
A new To Do item is added to To Do List.



- 3 Enter the text of the To Do item.
You can enter multiple lines of text.
- 4 Tap anywhere onscreen to deselect the To Do List item.
The item is deselected and the new item is recorded to To Do List.

Tips

- If no To Do List item is currently selected, writing in the Graffiti writing area automatically creates a new item.
- To display text that does not fit on the screen, tap the text line.



Managing tasks and things to do (To Do List)

Viewing To Do List items

You can check the items you recorded in To Do List.

- 1** Press the To Do List  button on the front panel.
The To Do screen appears.
- 2** Rotate the Jog Dial™ navigator to select the To Do List item that contains the note you want to view.
- 3** Press the Jog Dial navigator.
The notes of the selected item are displayed. If the item does not fit on the screen, rotate the Jog Dial navigator to scroll the screen.
- 4** Press the Jog Dial navigator.
The To Do List box reappears.

Viewing To Do List items by category

Press the Jog Dial navigator when To Do List is displayed but no To Do item is selected.

Each time you press the Jog Dial navigator, the display toggles through all the available categories.

Tip on selecting the desired category from the categories list

Tap the arrow ▼ at the upper right corner of the screen to display the category list. You can select the desired category from the list.





Managing tasks and things to do (To Do List)

Checking off a To Do List item

You can check off a To Do List item to remind you that you've completed it. You can set To Do List to record the date that you complete the To Do item, and you can choose to show or hide completed items. For details, see "Changing the appearance of To Do List" on page 69.

- 1** Press the To Do List  button on the front panel.
The To Do screen appears.
- 2** Tap to select the check box on the left side of the item.
The check box changes to .





Managing tasks and things to do (To Do List)


Working with To Do List

Setting the priority of an item

The priority setting for items lets you arrange the tasks in your To Do List according to their importance or urgency. The default setting for To Do List is to arrange items by priority and due date, with priority 1 items at the top. If you have a number of items in your list, changing an item's priority setting may move its position in the list.


On the To Do List screen, tap the Priority number on the left side of the item and then tap the desired Priority number.

You can select the Priority numbers 1 through 5, with 1 being the most important.



Tip

You can also set the priority from the To Do Item Details dialog box.





Managing tasks and things to do (To Do List)

Setting the due date for an item

You can associate a due date with any To Do List item. You can also sort the items that appear in the list based on their due date.

- 1 On the To Do List screen, tap the text of the item whose due date you want to set.
- 2 Tap Details.
- 3 Tap the arrow ▼ next to Due Date and then tap a desired due date from the drop-down list.

You can select one of the following options:

The screenshot shows a dialog box titled "To Do Item Details" with an information icon in the top right corner. The dialog contains the following elements:

- Priority:** A row of five buttons labeled 1, 2, 3, 4, and 5.
- Category:** A dropdown menu currently showing "Unfiled".
- Due Date:** A dropdown menu with options: "Today", "Tomorrow", "One week later", "No Date", and "Choose Date...". The "Choose Date..." option is highlighted.
- Private:** A checkbox that is currently unchecked.
- Buttons:** Three buttons at the bottom: "OK", "Cancel", and "Note".

- **Today:** Assigns the current date.
- **Tomorrow:** Assigns the next day's date.
- **One week later:** Assigns the date exactly one week from the current date.
- **No date:** Assigns no due date.
- **Choose Date:** Opens the Due Date screen, where you can choose any date from the calendar.

- 4 Tap OK.

Tip

If you turn on the Show Due Dates option in the To Do Show options dialog box, you can tap directly on the due date in To Do List to select a desired due date.



Managing tasks and things to do (To Do List)

Deleting an item

You can delete items from To Do List.


1 On the To Do List screen, tap the item you want to delete.

2 Tap Details.

The To Do Item Details dialog box appears.

3 Tap Delete.

The Delete To Do dialog box appears.



4 Tap OK to delete the item.

The selected event is deleted. To cancel deletion, tap Cancel.

Tip

If you check the “Save archive copy on PC” check box, the deleted item will be saved onto the Palm Desktop for CLIE software on your computer during the next HotSync® operation.




Managing tasks and things to do (To Do List)

Changing the appearance of To Do List

The Show Options dialog box enables you to control the appearance of To Do List.

1 On the To Do List screen, tap Show.

The To Do Preferences screen appears.



2 Change the Show Options settings.

You can choose any of the following settings:

- **Show Completed Items:** Displays your completed items in To Do List. If you turn off this setting, your To Do items disappear from the list when you complete (check) them.
- **Show Only Due Items:** Shows only the items that are currently due, past due, or have no due date specified. When this setting is active, items that are not yet due do not appear in the list until their due date.
- **Record Completion Date:** Replaces the due date with the actual date when you complete (check) the item. If you do not assign a due date to an item, the completion date still records when you complete the item.
- **Show Due Dates:** Displays the due dates associated with items in To Do List and displays an exclamation mark next to items that remain incomplete after the due date passes.
- **Show Priorities:** Shows the priority setting for each item.
- **Show Categories:** Shows the category for each item.

3 Tap OK.



Managing tasks and things to do (To Do List)

Using the To Do List menus

This section explains the menu commands specific to To Do List. For the Edit menu, see “Using the Edit menu” on page 110.

Record menus

Delete Item	Deletes the current To Do item. The Delete To Do dialog box appears.
Attach Note	Adds comments to the current To Do item. Choosing this menu item opens up a screen for entering comments.
Delete Note	Deletes comments from the current To Do item. Choosing this menu item opens up the Delete Note dialog box.
Purge	Allows you to delete any completed items from To Do List. Run this command to save memory if you find too many recorded To Do items in your CLIE handheld. Note By default, the items that you purge are restored and saved in Palm Desktop for CLIE software on your computer at the next HotSync operation. To delete the items completely, deselect the check box (<input type="checkbox"/>) for “Save archive copy on PC” in the Purge dialog box .
Beam Item	Sends the current To Do item to another Sony handheld via the infrared communications port.
Beam Category	Sends all the To Do items in the currently selected category to another Sony handheld via the infrared communications port.

Options menus

Font	You can select a desired font in the Select Font dialog box.
Phone Lookup	The Phone Number Lookup screen appears. If there is an Address Book entry, you can look up the phone number of the selected item.
Security	Hides the current item unless the password is entered. You can select the view option among Show Records, Mask Records, or Hide Records.
About To Do List	Shows the version information for To Do List.



Creating memos (Memo Pad)

You can use Memo Pad to make brief memos on your CLIE handheld. You can also display TXT or CSV (Comma Separated Value) document files created on your computer. A record in Memo Pad is called a “memo.”

Note


If the HOLD switch is in the protect position, you cannot operate your CLIE handheld.

Creating a new memo

A memo can contain up to 4,000 characters. The number of memos you can store is limited only by the memory available on your Sony handheld.

- 1 Press the Memo Pad  button on the front panel.

Memo Pad starts up. Memo Pad opens to display the last Memo Pad screen that you viewed.




Tip

Press the Memo Pad button repeatedly to cycle through the categories in which you have memos.

- 2 Tap New.

A new memo is created.




Continued on next page

Creating memos (Memo Pad)


3 Enter the text you want to appear in the memo.

To move down to a new line, tap the Enter key when using the software keyboard or write  when using Graffiti writing.



4 Tap Done or press the BACK button when you finish.

The first line of the memo is displayed.



Tips

- You can also create a new memo by beginning your memo in the Graffiti writing area on the Memo screen. The first letter is automatically capitalized and begins your new memo.
- While entering text, the text may overlap the Done or Details buttons. After you finish entering the text, the overlap disappears.

Creating memos (Memo Pad)

Reviewing memos

The first line of a memo appears in the Memo List. This makes it easy to locate and review your memos.

- 1** Press the Memo Pad  button on the front panel.

Memo Pad starts and the Memo list is displayed.

- 2** Rotate the Jog Dial™ navigator to select the memo you want to view.

If the desired memo is not displayed, rotate the Jog Dial navigator further to scroll up or down the memo list.

- 3** Press the Jog Dial navigator.

The content of the selected memo is displayed. If the memo text does not fit on the screen, rotate the Jog Dial navigator to scroll the screen.

- 4** Press the Jog Dial navigator.

The Memo list is displayed again.

Creating memos (Memo Pad)


Viewing memos by category

Press the Jog Dial navigator when the memo list is displayed but no memo is selected.

Each time you press the Jog Dial navigator, the display toggles through all the available categories.

Selecting the desired category from the categories list

Tap the arrow ▼ at the upper right corner of the screen to display the category list. You can select the desired category from the list.



Sorting memos


You can change the order in which Memo Pad shows your memos.

- 1** Press the Memo Pad  button on the front panel.
Memo Pad starts and the Memo list is displayed.
- 2** Tap the Menu  icon.
A menu of commands appears.
- 3** Tap Options, and then tap Preferences.
The Memo Preferences dialog box appears.

Continued on next page

Creating memos (Memo Pad)

4 Tap the desired order of the memos in the Sort by field.



- **Manual:** Sorts the memos manually.
- **Alphabetic:** Sorts the memos in numerical and then alphabetical order.

5 Tap OK.

To sort the memos manually

In step 4, select Manual to activate manual sorting.

Tap the memo you want to move in the Memo screen and drag it into the desired location. The memo is placed where you released the stylus.

The memos are renumbered accordingly.

Note

A change in the order of the memos in Memo Pad does not affect their order in the Palm™ Desktop for CLIE software. Consequently, the memo order in Memo Pad may differ from that in the Palm Desktop for CLIE software.

Creating memos (Memo Pad)

Editing memos

Deleting a memo

You can delete an unnecessary memo from Memo Pad.

- 1** On the Memo Pad screen, tap the memo you want to delete.
The contents of the memo you tapped appears.
- 2** Tap Details.
The Memo Details dialog box appears.



- 3** Tap Delete.
The Delete Memo dialog box appears.



- 4** Tap OK to delete the memo.
The selected record is deleted. To cancel deletion, tap Cancel.


Tip

If you select the “Save archive copy on PC” check box, the deleted memo will be saved onto the Palm Desktop for CLIE software on your computer during the next HotSync® operation.

Creating memos (Memo Pad)

Categorizing a memo

You can categorize your memo. In step 3 of “Deleting a memo,” tap the arrow ▼ next to Category to display the list of available categories and then tap the desired category for the memo.



Making a memo private

You can hide a memo that you mark as private. If you define a password for your CLIE handheld, you must enter it to display private records.

- 1** On the Memo Pad screen, tap the memo you want to mark as private.
- 2** Tap Details.
The Memo Details dialog box appears.
- 3** Tap and select the Private check box.



- 4** Tap OK.
The memo is marked as private. For details on hiding or masking private events, see “Protecting your data (Security)” on page 102.

Creating memos (Memo Pad)

Using the Memo Pad menus

This section explains the menu commands specific to Memo Pad. For the Edit menu, see “Using the Edit menu” on page 110. The Record and Options menus differ depending on the screen displayed.

Record menus

Beam Category	Sends all the memos in the currently selected category to another Sony handheld via the infrared communications port.
----------------------	---

New Memo	Creates a new memo.
-----------------	---------------------

Delete Memo	Deletes the current memo. The Delete Memo dialog box appears.
--------------------	---

Note

By default, the memos that you delete are restored and saved in Palm Desktop for CLIE software on your computer at the next HotSync operation. To delete the memos completely, deselect the check box () for “Save archive copy on PC” in the Delete Memo dialog box.

Beam Memo	Sends the current memo to another Sony handheld via the infrared communications port.
------------------	---

The Options menus

Font	You can select a desired font in the Select Font dialog box.
-------------	--

Phone Lookup	Phone Number Lookup screen appears. If there is an Address Book entry, you can look up the phone number of the selected memo.
---------------------	---

Preferences	Specifies how the memos are displayed. The Memo Preferences screen appears.
--------------------	---

Security	Hides the current memo unless the password is entered. You can select the view option among Show Records, Mask Records, or Hide Records.
-----------------	--

About Memo Pad	Shows the version information for Memo Pad.
-----------------------	---



Managing expenses (Expense)


You can use Expense for many disbursement purposes such as recording expenditures for business trips and personal expenses. A record in Expense is called an “item.”

Recording a new Expense item

Expense allows you to record the date, Expense type, and the amount you spent. You can sort Expense items into categories or add other information to an item.

- 1 Rotate the Jog Dial™ navigator to select Expense and then press the Jog Dial navigator. Or tap the Expense  icon on the Application Launcher screen.

The Expense screen appears.



- 2 Tap New.

New Expense item is created.



Continued on next page

Managing expenses (Expense)

3 Enter the amount of the expense.



The screenshot shows the 'Expense' screen with a dropdown menu set to 'All'. The entry '5/8 -Expense type- \$150' is visible. At the bottom, there are three buttons: 'New', 'Details...', and 'Show...'.

4 Tap **-Expense Type-** and select an Expense type from the drop-down list box.

The item you entered in Step 4 is saved when you select an Expense Type.



The screenshot shows the 'Expense' screen with the dropdown menu open, displaying a list of expense types: Airfare, BreakFast, Bus, Business Meals, Car Rental, Dinner, Entertainment, Fax, Gas, Gifts, Hotel, and Incidentals. The amount '150.00' is visible to the right of the list. At the bottom, there are three buttons: 'New', 'Details...', and 'Show...'.

Note

If you do not select an Expense type, the entered data will not be saved.

Tip

You can also create a new Expense item on the Expense screen by writing on the number side of the Graffiti® writing area. The first number you write begins your new Expense item.


Managing expenses (Expense)

Editing Expense items

Changing the display option

You can change display options of Expense items.

- 1 On the Expense screen, tap Show.
The Show Options dialog box appears.



- 2 Select the desired display mode option.
 - **Sort by:** Tap the arrow ▼ next to Sort by and then select Date or Type to sort Expense items.
 - **Distance:** Tap the arrow ▼ and then select Miles or Kilometers so that you can display Mileage entries in miles or kilometers.
 - **Show currency:** Shows or hides the currency symbol in the Expense list.
- 3 Tap OK.
The Expense items are sorted according the display mode option you selected.

Managing expenses (Expense)

Changing the date of an Expense item

The Expense item is initially displayed with the date when it is entered. If you want to record a past payment date for an Expense item, you can change the payment date of the item to the correct date.

- 1 On the Expense screen, tap the Expense item whose date you want to change.

The date is highlighted.




A screenshot of the 'Expense' screen. At the top, there is a title bar 'Expense' with a dropdown arrow and the text 'All'. Below the title bar is a list of expense items with their dates and amounts:

5/8	Bus	\$	20,00
5/8	Business Meals	\$	150,00
5/8	Parking	\$	40,00
5/8	Gifts	\$	35,00
5/8	Postage	\$	22,00

The date '5/8' in the 'Parking' row is highlighted with a dark background. At the bottom of the screen, there are three buttons: 'New', 'Details...', and 'Show...'.

- 2 Tap the date area of the selected Expense item.

The Date screen appears.



A screenshot of the 'Date' selection screen. At the top, there is a title bar 'Date'. Below the title bar, there is a year selector '2001' with left and right arrows. Below the year selector is a grid of months:

Jan	Feb	Mar	Apr	May	Jun
Jul	Aug	Sep	Oct	Nov	Dec

Below the month grid is a calendar grid with days of the week (S, M, T, W, T, F, S) and dates. The date '8' is highlighted with a dark background. At the bottom of the screen, there are two buttons: 'Cancel' and 'Today'.

- 3 Tap the desired date.

The date is changed.

Managing expenses (Expense)

Entering receipt details for an Expense item

You can add details to an Expense item in the Receipt Details screen.

- 1 On the Expense screen, tap the Expense item to which you want to assign details.
- 2 Tap Details.

The Receipt Details dialog box appears.



3 Change the Receipt Details settings

You can choose any of the following options:

- **Category:** Specify the category of the Expense item. The Expense has two sample categories named “New York” and “Paris” which may be used to sort Expense items by the destination of the business trip. To rename an existing category or add a new category, tap the arrow ▼ and choose a category from the Edit Categories drop-down list box.
- **Type:** Tap the arrow ▼ and select an Expense type from the drop-down list box.
- **Payment:** Tap the arrow ▼ and select a payment method from the drop-down list box.
- **Currency:** Tap the arrow ▼ and select the currency in which you made the payment. Expense can show a maximum of four currencies. You can also change the currencies to be displayed.
- **Vendor:** Enter the name of the vendor associated with Expense.
- **City:** Enter the name of the payee (normally a company name) and the name of the city where the company is located. For example, you may specify “Rose Cafe” as the payee of a business lunch charge and “Tokyo” as the location.

Continued on next page

Managing expenses (Expense)

- **Attendees:** Expense opens the Attendees screen which looks like a memo screen of Memo Pad. In this screen, you can enter the names of attendees and purposes of expenditures. To display the address information in Address Book, tap Address Lookup.

4 Tap OK.

Printing an Expense report

By performing a HotSync® operation to transfer your latest Expense data to your computer, the Palm™ Desktop for CLIE software makes it easy to print from a printer connected to your computer. You can use the Expense data as an Expense report by changing the preferences.

- 1 Perform a HotSync operation to transfer the Expense data from your CLIE handheld to your computer.
- 2 Select Print from the File menu on the Expense list screen of the Palm Desktop for CLIE software.
The Print dialog box appears.
- 3 Change the Print Range options as needed.
 - **Categories displayed:** Prints all the Expense items in the categories displayed. To display the items contained in all the categories, choose All from the category selection list on the upper right of the Expense list area (left screen).
 - **Selected categories:** Prints the Expense items in selected categories only.
- 4 Change the Print Options as needed.
 - **Prints only an Expense overview:** Prints only daily amounts of disbursement for each Expense type in a tabular format. Select this option to use a disbursement record as an Expense report.
 - **Prints only the Expense data:** Prints all disbursement records for each expense type.
 - **Prints both:** Prints both an overview and disbursement records.

Continued on next page

Managing expenses (Expense)

- **Prints currency:** Enabled only when printing an Expense overview. When you click this option, you can calculate the total amounts of a single currency in a table. This is useful when your data includes items in several currencies.
- **Output comments:** When you click this option, you can also print comments attached to the Expense data.

5 Click OK.

Printing starts.

Notes

- The unit of Travelling Distance is either km. (kilometers) or mi. (miles).
- When you select Prints currency, Travelling Distance values are converted into amounts of allowances per distance paid when travelling expenses are calculated.

Customizing the Currency list

You can change the currencies and symbols that appear for currencies to be used in Expense.

To change the currency list

- 1 On the Expense screen, tap the Expense item whose currency type you want to change.
- 2 Tap Details.
The Receipt Details dialog box appears.
- 3 Tap the arrow ▼ next to Currency and then tap Edit currencies from the drop-down list.
The Select Currencies dialog box appears.



The screenshot shows a dialog box titled "Select Currencies". Inside, it says "Select the currencies that display in currency list." Below this are five rows, each with a label and a dropdown menu:

- Currency 1: ▼ United States
- Currency 2: ▼ EU (Euro)
- Currency 3: ▼ United Kingdom
- Currency 4: ▼ Germany
- Currency 5: ▼ None

At the bottom of the dialog box are two buttons: "OK" and "Cancel".

Continued on next page


Managing expenses (Expense)

- 4 Tap the arrow ▼ for each Currency and then tap the country whose currency you want to display in the Currency list.
- 5 Tap OK to close the Select Currencies dialog box.
- 6 Tap OK.

To change your default currency

You can change the currency displayed as the default in the Currency list.

- 1 On the Expense screen, tap the Menu  icon.
The menu is displayed.
- 2 Tap Options and then Preferences.
The Preferences dialog box appears.



- 3 Tap the arrow ▼ next to Default Currency and then tap the currency symbol you want to appear in Expense.
- 4 Tap OK.

Managing expenses (Expense)

To create a new currency symbol

If the currency you want to use is not included in the Currency list, you can create your own custom country and currency symbol.

- 1 On the Expense screen, tap the Menu  icon.

The menu is displayed.

- 2 Tap Options and then Custom Currencies.

The Custom Currencies dialog box appears.

- 3 Tap one of the four country boxes.

The Currency Properties dialog box appears.



Currency Properties

Country:

Symbol:

OK Cancel

- 4 Enter the name of the country and a currency symbol, and then tap OK.

Tips

- To use a newly defined currency symbol as a standard currency symbol, it is necessary to select the target currency symbol in advance in the Preferences option.
- To use a currency symbol only for a specific Expense item, select the currency symbol in the Receipt Details dialog box of that Expense item.

Managing expenses (Expense)

Using the Expense menus

This section explains the menu commands specific to Expense. For the Edit menu, see “Using the Edit menu” on page 110.

Record menus

Delete Item

Deletes the current Expense item. The Delete Expense dialog box appears.

Note

By default, the items that you delete are restored and saved in Palm Desktop for CLIE software on your computer at the next HotSync operation. To delete the items completely, deselect the check box () for “Save archive copy on PC” in the Delete Expense dialog box.

Purge

Allows you to delete any category that is no longer used from the Expense category set. Run this command to save memory if you find too many Expense items in your CLIE handheld.

Options menus

Preferences

- **Use automatic fill:** Lets you select an Expense type by writing the first letter of an Expense type in the Graffiti writing area. For example, if you write the letter “T,” it enters the “Taxi” Expense type. Writing “T” and then “E” enters “Telephone” which is the first Expense type beginning with the letters “TE.”
 - **Default Currency:** Specifies the currency to be displayed as the default currency.
-

Custom Currencies

You can create and add a new currency if you cannot find the currency you want to use in Expense.

About Expense

Shows the version information for Expense.




Using Calculator (Calc)

Calculating with Calculator

Calculator lets you perform general mathematical functions, such as addition, subtraction, multiplication, and division.

1 Do either of the following to start the Calculator:

- Tap the Calculator  icon.
- Rotate the Jog Dial™ navigator to select Calc and then press the Jog Dial navigator.
- Tap the Calc  icon on the Application Launcher screen.
The Calculator screen appears.



2 Perform calculations using Calculator.

To use Calculator, tap the numbers and symbol icons on the screen with the stylus.



Using Calculator (Calc)

Using the Calculator buttons

Calculator has several buttons to help you perform calculations.

CE	Clears the last number you entered. Use this button if you make a mistake while entering a number in the middle of a calculation. This button enables you to re-enter the number without starting the calculation over.
C	Clears the entire calculation and enables you to begin a new calculation.
+/-	Toggles the current number between a negative and positive value. If you want to enter a negative number, enter the number first and then press the +/- button.
M+	Places the current number in memory. Each new number you enter with the M+ button is added to the total stored in memory. The number that you add can be either a calculated value or any number you enter by pressing the number buttons. Pressing this button has no effect on the current calculation (or series of calculations); it merely places the value into memory until it is recalled.
MR	Recalls the stored value from memory and inserts it in the current calculation.
MC	Clears any value that is stored in the Calculator memory.

Using the Calculator menus

Copy, Paste	Copies a number from Calculator and pastes it into another application. Similarly, you can also paste numeric values you copied from another application such as Expense into Calculator.
Recent Calculations	You can review the last series of calculations.
About Calculator	Shows the version information for Calculator.

Performing common tasks

This section explains how to perform tasks that you can do in most or all of the basic applications.

Using the Application Launcher

This section explains how to switch between applications, how to change application settings so they are customized to your work methods, and how to categorize applications so you view them in related groups.

- 1 To open the Application Launcher screen, tap the Home  icon.



Tip

In addition to providing a way for you to open applications, the Application Launcher screen displays the current time, battery level, and application category.

Selecting applications

To open an application, choose from the following options:

- Tap the icon of the application you want to open. If you have many applications installed on your CLIE handheld, tap the scroll bar to see all the available applications.
- Rotate the Jog Dial™ navigator to select the application. Push the Jog Dial navigator to launch the selected application.
- Press an application button , , , or  on the front panel to display the selected application immediately.

Performing common tasks


Categorizing applications

The category feature enables you to manage the number of application icons that appear in the Application Launcher screen. You can assign an application to a category and then display a single category or all your applications.

To categorize an application

- 1 Tap the Home  icon.
- 2 Tap the Menu  icon.
- 3 Tap Category from the App menu.

The Category screen appears.



- 4 Tap the arrow ▼ next to each application to select a category from the drop-down list.

Tip

To create a new category for an application, tap Edit Categories from the drop-down list. Tap New, enter the category name, and then tap OK to add the category. Tap OK again.

- 5 Tap Done.

Performing common tasks

To display applications by category

- 1 Tap the Home  icon.
- 2 Do one of the following:
 - Tap the Home  icon repeatedly to cycle through all the categories.
 - Tap the arrow ▼ in the upper right corner of the screen and then tap the desired category from the drop-down categories list.
 - Push the Jog Dial navigator repeatedly while no applications are highlighted.


Changing the Application Launcher display

By default, the Application Launcher displays each application as an icon. As an alternative, you can display applications in a list format.

You can also choose to view the same category of applications each time you open the Application Launcher screen.

To change the view of applications

- 1 Tap the Home  icon.
- 2 Tap the Menu  icon.
The menu is displayed.
- 3 Tap Options, and then tap Preferences.
The Preferences screen is displayed.



- 4 Tap the arrow ▼ next to View By and then tap List.

Continued on next page

Performing common tasks

5 Tap OK.

The applications are displayed in a list.




To open the Application Launcher screen to the last-opened category

In step 4, tap the Remember Last Category check box to select it.

To display application's Pop-up menu by the Jog Dial navigator

In step 4, tap the arrow ▼ next to Jog Select and then tap PopUp.



Performing common tasks

Categorizing records

You can categorize records in Address Book, To Do List, Memo Pad, and Expense applications for easy retrieval. (Date Book does not have categories.) When you create a record, it is automatically assigned to the currently displayed category. For example, if the All category is displayed, the record is assigned to the Unfiled category. A record can remain unfiled or it can be assigned to a category at any time.

System-defined and user-defined categories

By default, your CLIE handheld includes system-defined categories, such as All and Unfiled, and user-defined categories, such as Business and Personal. You cannot modify the system-defined categories, but you can rename or delete the user-defined categories. In addition, you can create your own user-defined categories. You can have a maximum of 15 user-defined categories in each application.

Tips

- Address Book contains the QuickList user-defined category, in which you can store the names, addresses, and phone numbers that you might need in emergencies (doctors, fire department, lawyers, etc.).
- Expense contains two user-defined categories, New York and Paris, to show how you might sort your expenses according to different business trips.

Performing common tasks

Moving a record into a category

- 1 Tap the record that you want to categorize.
- 2 Tap Details.

For Address Book only: Tap Edit.

The Address Edit screen appears.



- 3 Tap the arrow ▼ next to Category to display the list of available categories.
- 4 Tap the desired category for the item.
- 5 Tap OK.

Displaying the category of records

- 1 Tap the arrow ▼ at the upper right corner of the screen.
A list of available categories appears.




- 2 Tap the category you want to view.
The list screen now displays only the records assigned to that category.

Performing common tasks

Defining a new category

- 1** Tap the arrow ▼ at the upper right corner of the screen.
A list of available categories appears.
- 2** Tap Edit Categories.
The Edit Categories screen is displayed.
- 3** Tap New.
The Edit Categories dialog box is displayed.



- 4** Enter a new category name and then tap OK.
You can assign any of your entries to the new category.

Performing common tasks

Finding records

Your CLIE handheld lets you find information by entering text in the Find option dialog box or searching for a phone number using the Phone Lookup option. These two options are available for all the basic CLIE applications.

Each application offers ways to find information:

- **Date Book, To Do List, Memo Pad:** Phone Lookup displays the Address List screen and lets you add the information that appears in this list to a record.
- **Address Book:** The Look Up line lets you enter the first letters of a name to scroll immediately to that name.
- **Expense:** Lookup displays the names in your Address Book that have data in the Company field. You can add these names to a list of attendees associated with an Expense record.

Using the Find option

The Find option lets you locate any text you specify in any application. For example, if the text appears in Address Book and Date Book, the Find option displays both occurrences in the Find dialog box.

- 1 Tap the Find  icon.

The Find dialog box appears.



- 2 Enter the text you want to find.

You can enter letters, symbols, or numbers.




Continued on next page

Performing common tasks

3 Tap OK.

Find searches for the text in records and notes and then displays the results.



4 Tap the text in the find result list that you want to review.

The application associated with the data automatically starts to display the data.

To stop searching midway

Tap Stop. To resume the search, tap Find More.

Note

The Find option is not case sensitive; searching for "sony" also finds "Sony."

Tip

Select text in an application before tapping the Find icon to automatically place the text in the Find dialog box.

Performing common tasks

Using the Phone Lookup option

The Phone Lookup option lets you find a telephone number from the Address list screen and lets you add the information that appears in this list to a record. For example, you can add a telephone number from the Address list to an entry in Memo Pad.

- 1 Display the record in which you want to insert a phone number.


The record can be in Date Book, To Do List, or Memo Pad.

- 2 Tap the Menu  icon.

The menu of the application appears.

- 3 Tap Options and then Phone Lookup.

The Phone Number Lookup screen appears.



Phone Number Lookup:	
Abrams, Liz	###-###-#### W
Accessories	###-###-#### W
Adams, Ben	###-###-#### H
Becker, Ran	***@***.ne E
Carter, Melanie	###-###-###...M

Look Up:

- 4 Tap the phone number you want to add.

Tip to quickly find a phone number

Enter the first few letters of the name you want to find in the Look Up field in the lower screen.

Continued on next page

Performing common tasks

5 Tap Add.

The Phone Lookup closes and the name and phone number are added to the record you displayed in step 1.



To activate Phone Lookup with Graffiti

Write the Graffiti® Command stroke  to activate Phone Lookup.

Phone Lookup using text

Drag and highlight text and then write the Graffiti Command stroke . The selected text is replaced with the found name and phone number.

If multiple records are found, the Phone Number Lookup screen appears.

Performing common tasks

Protecting your data (Security)

Your CLIE handheld includes a Security application that allows you to protect your data from unauthorized users.

In Security, you can do the following:

- Lock and turn off your CLIE handheld so that it does not operate until you enter the correct password.
- Mask all records that you mark as private so the information appears greyed out.
- Hide all records that you mark as private so they do not appear on any screen.

You can mask or hide private records with or without a password. Without a password, private records are hidden or masked until you set the Security application to show them. With a password, you must enter the password to view the private records.

Assigning a password

You can assign a password to protect your private records and to lock your CLIE handheld.

- 1 Rotate the Jog Dial navigator to select Security and then press the Jog Dial navigator. Or tap the Security  icon on the Application Launcher screen.

The Security screen appears.




Continued on next page

Performing common tasks

2 Tap Unassigned.

The Password dialog box appears.



3 Enter a password and then tap OK.

The dialog box for verifying the password appears.

4 Enter the same password again to verify it and then tap OK.

Your password is assigned. In Password, "Assigned" is displayed.

Changing or deleting a password


You can change or delete the password you assigned. You should enter the current password before you can change or delete it.

1 Rotate the Jog Dial navigator to select Security and press the Jog Dial navigator. Or tap the Security icon on the Application Launcher screen.

The Security screen appears.

2 Tap Assigned.

The Password dialog box appears.



3 Enter the current password and then tap OK.

The dialog box used to enter a new password appears.

4

- To change the password, enter a new password and then tap OK.

- To delete the password, tap Delete.

Performing common tasks

If you forget your password

If you forget your password, you can delete it. Note, however, that deleting a forgotten password also deletes all entries and records marked as Private. (If you synchronize with your computer before deleting a forgotten password, you can restore your private records at the next HotSync® operation.)

1 Tap Lost Password in step 3.

The Delete Password dialog box appears.



2 Tap Yes.

Your password and private records are deleted.

Performing common tasks

Locking your CLIE handheld with a password

You can lock your CLIE handheld so that you have to enter your password to operate it.

Notes

If you lock your CLIE handheld, you must enter the exact password to restart your CLIE handheld. If you forget the password, you must perform a hard reset to resume using your CLIE handheld. Performing a hard reset deletes all the records in your CLIE handheld; however, you can restore all synchronized data at the next HotSync® operation.

- 1** Perform a HotSync operation to synchronize the data between your CLIE handheld and your computer.
See “Chapter 3: Exchanging and updating data using a HotSync® operation” for more information.
- 2** Assign a password.
Follow the steps described in “Assigning a password.”
- 3** Rotate the Jog Dial navigator to select Security and press the Jog Dial navigator. Or tap the Security  icon on the Application Launcher screen.
The Security screen appears.




Continued on next page

Performing common tasks

4 Tap Lock & Turn Off.

The System Lockout dialog box appears.



5 Tap Off & Lock.

Your CLIE handheld is turned off and locked.

To start your CLIE handheld, turn it on and enter the password.



Performing common tasks

Making records private

In all basic applications except Expense, you can make individual records private. Private records remain visible and accessible, until you select the Security setting to hide all private records.

To mask or hide private records


You can mask or hide your private records. To view the masked or hidden records, you need to enter the password.

- 1 Rotate the Jog Dial navigator to select Security or tap the Security  icon on the Application Launcher screen.

The Security screen appears.

- 2 Tap the arrow ▼ next to Current Privacy to select Mask Records or Hide Records from the drop-down list.

- **Mask Records:** Masked records appear as grey placeholders in their position with a lock mark.
- **Hide Records:** Hidden records disappear completely from the screen.



When you select Mask Records



When you select Hide Records

- 3 Tap OK.

To display private records

In step 2, select Show Records.

If you have a password, the Show Records screen appears. Enter the password and then tap OK.

Performing common tasks

Attaching notes


In all basic applications except Memo Pad, you can attach a note to a record. A note can be up to several thousand characters long. For example, for an appointment in Date Book, you can attach a note with directions to a location.

- 1 Tap the record to which you want to add a note.
- 2 Address Book only: Tap Edit.
The Address Edit screen appears.
- 3 Tap Details.
- 4 Tap Note.
- 5 Enter your note.



- 6 Tap Done.

A small note icon appears at the right side of any item that has a note.



Tip

To display the note, tap the note icon. You can review or edit the note. To delete the note, tap Delete and then tap Yes.

Performing common tasks


Purging records

If outdated records of Date Book, To Do List, or Expense take up memory on your CLIE handheld, it's a good idea to remove them by using Purge. If you think Date Book or To Do List records might prove useful later, you can save them in an archive file on your computer. Purging is not available in Address Book or Memo Pad, so delete outdated records from these applications.


- 1 Open the application.
- 2 Tap the Menu  icon.
- 3 Tap Purge from the Record menu.

The Purge screen appears.

Date Book, To Do List



Expense



Date Book, To Do List: Tap the arrow ▼ and select how old a record must be to be purged. If you want to save a copy of the purged records on your computer, select the “Save archive copy on PC” check box. If you want to delete the records completely, clear it.

Expense: Tap the category you want to delete.

- 4 Date Book, To Do List: Tap OK.

Expense: Tap Purge.

If you chose to save a copy of the purged records, your CLIE handheld transfers them to an archive file on your computer the next time you perform a HotSync operation.

Note

Purging does not happen automatically. You must tap the command to make it happen.

Performing common tasks

Using the Edit menu

The Edit menu is available with any screen where you enter or edit text. In general, commands available in the Edit menu apply to the text that you select in an application.

Selecting text in an application

- 1 Tap the beginning of the text that you want to select.
- 2 Drag the stylus over the text to highlight it (in black).

Notes

- You can also double tap to select a word, or triple tap to select a line of text.
- You can also drag across the text to select additional words, or drag down to select a group of lines.

Edit menu

To display the Edit menu, tap the Menu  icon and then select Edit.


Undo	Reverses the action of the last edit command. For example, if you used Cut to remove text, Undo restores the text you removed. Undo also reverses deletions done by using backspace.
Cut	Removes the selected text and stores it temporarily in the memory of your CLIE handheld. You can paste the text you cut into another area of the current application or into a different application.
Copy	Copies the selected text and stores it temporarily in the memory of your CLIE handheld. You can paste the text that you copy into another area of the current application or into a different application.
Paste	Inserts the text that you cut or copied at the selected point in a record. The text you paste replaces any selected text. If you did not previously cut or copy text, Paste does nothing.
Select all	Selects all of the text in the current record or screen. This enables you to cut or copy all of the text and paste it elsewhere.
Key board	Opens the onscreen keyboard. When you finish with the onscreen keyboard, tap Done.
Graffiti Help	Opens screens that show all the Graffiti character strokes. Use this command any time you forget a stroke for a character.

Performing common tasks

Choosing fonts

In all basic applications except Expense, you can change the font style to make text easier to read. You can choose a different font style for each application.

- 1 Open an application.
- 2 Tap the Menu  icon.
The menu is displayed.
- 3 Tap Options, and then tap Font.
- 4 Tap the font style you want to use.
You can select small, bold, or large font.



- 5 Tap OK.
The text in the application is displayed in the selected font style.

Chapter 3

Exchanging and updating data using a HotSync® operation

This chapter describes how to select HotSync® operation options and how to perform a HotSync operation via cradle, infrared communications port, or network. Other advanced HotSync operations include how to use multiple CLIE handhelds, how to use file link functions, and how to import data from Windows applications.


Contents

What is a HotSync® operation?	113
Performing a local HotSync® operation with the cradle	114
Using the Palm™ Desktop for CLIE software	116
Starting the Palm Desktop for CLIE software	116
Basic operations of the Palm Desktop for CLIE software	116
Locating the Palm Desktop for CLIE components	117
Advanced HotSync® operations	118
Setting the HotSync® setup options	118
Customizing HotSync application settings (Conduit)	120
Creating a user profile to control multiple CLIE handhelds	122
Conducting an IR HotSync operation	124
Conducting a HotSync operation via modem	127
Conducting a HotSync operation via a network	133
Importing data from a Windows application	136

What is a HotSync® operation?

A HotSync® operation is a one-step operation that allows you to synchronize data between your CLIE handheld and your computer. With just one press on the HotSync button, you can synchronize your CLIE handheld application data with the Palm™ Desktop for CLIE software data on your computer, back up the data of your CLIE handheld on your computer, or install add-on applications.

HotSync operation allows you to do the following:



- ① Synchronize the Date Book, the Address Book, the To Do List, the Memo Pad, and the Expense data on your CLIE handheld and your computer. The Palm Desktop for CLIE software can manage the data of multiple CLIE handhelds independently.
- ② Back up the data stored on your CLIE handheld onto your computer. Synchronization ensures that your data is always safe and up-to-date. In case you need to perform a hard reset, a HotSync operation allows you to restore the data.
- ③ Import the data on your computer or install add-on applications onto your CLIE handheld.


Note

You cannot perform an IR HotSync operation with a computer running the Windows® 2000 Professional operating system.

Performing a local HotSync® operation with the cradle

This section describes how to perform a HotSync® operation using the cradle (local HotSync), assuming that you have done all the necessary preparations and installations for your CLIE handheld and your computer. For the required preparations and software installation, and for information on performing a HotSync for the first HotSync operation, see the Read This First manual.

- 1** Place your CLIE handheld on the cradle.
- 2** Press the HotSync  button on the front panel of the cradle. The HotSync operation starts.



When the HotSync operation is complete, a message showing the HotSync completion is displayed on your CLIE handheld.

Note

Do not remove your CLIE handheld from the cradle until the HotSync operation is complete. Otherwise the Palm Desktop for CLIE software may not quit normally.

If the HotSync operation does not start

Make sure that the HotSync  icon is displayed in the Windows task tray on your computer screen and Local is not selected from the shortcut menu. If the HotSync  icon is not shown in the task tray, click Start, point to Programs, Sony Handheld, and then click HotSync Manager. Click the HotSync  button on the cradle to start the HotSync operation.

Performing a local HotSync® operation with the cradle

If a message is displayed stating that the selected COM port is not available

Follow the procedures below. If the same message appears again, uninstall the Palm Desktop for CLIE software and then re-install it.

- 1 Click the HotSync  icon in the Windows task tray (bottom-right corner of the taskbar).

A shortcut menu is displayed.

- 2 Make sure that Local is not selected.

If it is selected, click Local to clear it.

Notes

- Even if the HotSync operation is performed via a USB connector and the cradle, “Serial” is indicated.
- Do not remove your CLIE handheld from the cradle during a HotSync operation.
- Do not push the HotSync button during a HotSync operation. It might cause errors and force termination of the operation.
- Do not enter power saving mode during a HotSync operation. If your computer enters power saving mode during a HotSync operation, the HotSync Manager will be forced to terminate.

To control multiple CLIE handhelds from a computer

You have to create a user profile for each CLIE handheld. See “Creating a user profile to control multiple CLIE handhelds” on page 122 for creating a use profile.

To change the user name

- 1 In the Palm™ Desktop for CLIE window, click Users from the Tools menu.

The Users dialog box is displayed.

- 2 Click the user name you want to change in the list box and then click Rename.

The Rename User dialog box is displayed.

- 3 Enter a new user name and then click OK.

Your CLIE handheld user name is changed at the next HotSync operation.

Using the Palm™ Desktop for CLIE software

The Palm™ Desktop for CLIE software duplicates Date Book, Address Book, To Do List, Expense, and Memo Pad applications on your CLIE handheld, so you can view, enter, and modify data stored on your CLIE handheld. You can also import data from Windows applications onto your CLIE handheld.

Starting the Palm Desktop for CLIE software

Double-click the Palm Desktop for CLIE software icon on the Windows desktop or click Start, select Programs, Sony Handheld, and then click Palm Desktop for CLIE.

The Palm Desktop for CLIE software starts.

To quit the Palm Desktop for CLIE software

Click the close  button in the upper right of the screen or click File, and then Exit.


Basic operations of the Palm Desktop for CLIE software

Click the icon of the application that you want to use. The screen switches to the selected application screen.

Basic operations for each application are the same as those of the corresponding CLIE application. For details, see the Palm Desktop online help. To display the online help, click Help and then Palm Desktop Help.

Using the Palm™ Desktop for CLIE software

Locating the Palm Desktop for CLIE components



1 List pane

Displays the records in the current Desktop application.

2 Application Launch bar

Provides one-click access to each Desktop application. Click an icon to open its associated application.

3 Install Tool icon

Displays the Install Tool dialog box to select the application you want to install onto your CLIE handheld the next time you perform a HotSync operation.

4 User name display

Displays the user name of the owner of the information being displayed.

5 Record pane

Displays full details of the record that is selected in the List pane. The information displayed here is the same as that displayed on your CLIE handheld's Details screen.


Advanced HotSync® operations

Setting the HotSync® setup options

You can change how to start the HotSync® Manager or make the local HotSync settings.

- 1 Click the HotSync  icon in the Windows® task tray (bottom-right corner of the taskbar) and then select Setup from the shortcut menu.

The Setup dialog box appears.



- 2 Click the General tab to select one of the following options.

If you are not sure which option to use, keep the default setting: (Always available)

- **Always available:** Adds the HotSync Manager to the Startup folder and starts the HotSync Manager to monitor the USB port as soon as Windows® is started. This allows you to perform a HotSync operation even when the Palm Desktop for CLIE software is not running.
- **Available only when the Palm Desktop is running:** Starts the HotSync Manager when you start the Palm Desktop for CLIE software.
- **Manual:** Starts the HotSync Manager only when you select HotSync Manager from the Windows® Start menu.

Continued on next page

Advanced HotSync® operations

- 3** Click the Modem tab to display the modem settings and then adjust the options as needed.
See “Conducting a HotSync operation via modem” on page 127 for more information.
- 4** If you are attached to a network, click the Network tab to display the network settings and then adjust the options as needed.
See “Conducting a HotSync operation via a network” on page 133 for more information.
- 5** Click OK.

Advanced HotSync® operations

Customizing HotSync application settings (Conduit)

What is a “Conduit”?

For each application, you can define a set of options that determines how records are handled during synchronization. Each set of these options is called a “conduit.” By default, a HotSync operation synchronizes all files between your CLIE handheld and the Palm Desktop for CLIE software.


In general, you should leave the settings as they are to synchronize all files. The only reason you might want to change these settings is to overwrite data on either your CLIE handheld or the Palm Desktop for CLIE software, or to avoid synchronizing a particular type of file because you do not use it.

In addition to the conduits for Date Book, Address Book, To Do List, Memo Pad, and Expense, the Palm Desktop for CLIE software offers System and Install conduits. The System conduit backs up the system information stored on your CLIE handheld. The Install conduit installs add-on applications to your CLIE handheld.

- 1 Click the HotSync  icon in the Windows task tray (bottom-right corner of the taskbar) and then select Custom from the HotSync Manager menu.

Or, select Custom from the HotSync menu of the Palm Desktop for CLIE software.

The Custom dialog box appears.




- 2 Select the appropriate user name you are using on your CLIE handheld from the drop-down list.
- 3 Select an application in the Conduit list.

Continued on next page

Advanced HotSync® operations

4 Click Change.

The Change HotSync Action dialog box appears.



5 Click the direction in which you want to write data, or click Do nothing.

6 Click OK.

7 Repeat steps 2 through 6 to change conduit settings for other applications (or users).

8 Click Done.

Notes

- Any change in the HotSync setting from the default affects only the next HotSync operation. Thereafter, the HotSync Actions revert to their default settings. To use a new setting on an ongoing basis, check the Set as default box.
- To restore the default settings, click Default in the Custom dialog box.

Advanced HotSync® operations

Creating a user profile to control multiple CLIE handhelds

If your company introduces multiple CLIE handhelds to its employees, for example, you can create a user profile (such as a company phone list) to load the data into several CLIE handhelds without associating that data with a user name.

Notes


- This feature is designed only for the first HotSync operation (before you have assigned a User ID to a particular CLIE handheld).
- For the procedure used to send a profile after setting user names, see “Synchronizing with external data (File Link)” on page 138.

Creating a profile

1 Start the Palm Desktop for CLIE software.

2 Select Users from the Tools menu.

The Users dialog box appears. If no user profile is created, the New Profile dialog box is displayed. Skip to step 4.



3 Click Profiles.

The Profiles dialog box appears.

Continued on next page

Advanced HotSync® operations

4 Click New.

The New User dialog box appears.



5 Enter a user name and then click OK.

6 Repeat steps 4 and 5 for each profile you want to create.

7 Click OK.

8 Select profiles from the User list, and create data for the profile (e.g., company phone list, etc.).

Transferring a created profile

1 Place a CLIE handheld without a user name on the cradle.

2 Press the HotSync button on the cradle.

The Users dialog box appears.

3 Click Profiles.

The Profiles dialog box appears.

4 Select the profile you want to transfer to your CLIE handheld, and then click OK.

5 Click Yes.

The selected profile is transferred to your CLIE handheld.

The next time you perform a HotSync operation, the Palm Desktop for CLIE software shows a dialog box where you can specify a user name for your CLIE handheld.

Advanced HotSync® operations

Conducting an IR HotSync operation

You can use the IR (infrared) port of your CLIE handheld to perform an IR HotSync operation with a computer equipped with an IrDA (Infrared Data Association) IR port. An IR HotSync operation allows you to perform a HotSync operation without using the cradle.

Before you start performing an IR HotSync operation

Check the following:

- Your computer's operating system is not Windows® 2000. (You cannot perform an IR HotSync operation with a computer running the Windows 2000 operating system.)
- Your computer is equipped with an infrared port supporting the IrDA standards.
- The infrared port of your computer is enabled for Windows use.
To enable the IR port with Windows, see the manual of the computer you are using or the Windows online help.
- Which port number is allocated to the infrared port.
Check the infrared port number in the Infrared Monitor in the Control Panel. For information on the Infrared Monitor, see the manual of the computer you are using or the Windows online help.

Preparing your computer

To perform an IR HotSync operation, you have to allocate a virtual port to an IR HotSync operation.

- 1** Click the HotSync  icon in the Windows task tray (bottom-right corner of the taskbar) and then select Local from the shortcut menu.
- 2** Click the HotSync  icon in the Windows task tray again and then select Setup from the shortcut menu.
The setup dialog box is displayed.

Continued on next page

Advanced HotSync® operations

- 3 Click the Local tab to change the setting for an IR HotSync operation as needed.
 - **Serial Port:** Specifies a virtual port for an infrared port. If you are not sure of the connection port, see the Infrared Monitor in the Windows Control Panel.
 - **Speed:** Determines the speed at which data is transferred. Try the “As Fast As Possible” rate first, and then adjust downward if you experience problems.
- 4 Tap OK.

Your computer is ready to perform an IR HotSync operation.

Note

When performing a local HotSync operation with the cradle after you make the HotSync Setup settings for an IR HotSync operation, you should restore the local HotSync settings. For details, see “To restore the local HotSync settings” on page 126.

Performing an IR HotSync operation

After you prepare your computer and your CLIE handheld, and then select your Conduit Setup options, you are ready to perform an IR HotSync operation.

- 1 Rotate the Jog Dial™ navigator to select HotSync and then press the Jog Dial navigator. Or tap the HotSync  icon on the Application Launcher screen.

The HotSync dialog box appears.
- 2 Tap Local.
- 3 Tap the arrow ▼ beneath the HotSync icon and then select IR to a PC/Handheld from the drop-down list.
- 4 Point the IR port of your CLIE handheld directly at the IR port of the receiving computer.

Continued on next page 

Advanced HotSync® operations

Tip

For best results, your computer and your CLIE handheld should be 4 to 8 inches (approximately 10 to 20 centimeters) apart, and the path between your CLIE handheld and the computer must be clear of obstacles.

5 Tap the icon.

The HotSync operation starts. Wait for the message showing that the HotSync operation is complete.

To restore the local HotSync settings

- 1 Connect the cradle to your computer.
- 2 Click the HotSync  icon in the Windows task tray and clear the check-mark of Local from the shortcut menu.
- 3 Click the HotSync  icon in the Windows task tray again and then select Setup from the shortcut menu.


The setup dialog box is displayed.
- 4 Click the Local tab to display the setting for a local HotSync operation as needed.
- 5 Click OK.

Your computer is now ready to perform a local HotSync operation.

Advanced HotSync® operations

Conducting a HotSync operation via modem

You can use a modem to synchronize your CLIE handheld when you are away from your computer. A HotSync operation via modem allows you to back up your CLIE data to your computer away from your computer.



Notes

- The first HotSync operation must be local, using the cradle. After that, you can perform a modem HotSync operation.
- It may take many minutes to complete a HotSync operation via modem. To minimize the time required to synchronize data with a modem, we suggest you define the files and/or applications you synchronize during a modem HotSync operation in advance. For details, see “To select the conduits for a modem HotSync operation” on page 131.

Before you start performing a HotSync operation via modem

Check the following:


- A modem or terminal adapter is connected to your computer.
- The CLIE Modem PEGA-MD700 (not supplied) must be connected to your CLIE handheld.
- The Palm Desktop for CLIE software must be properly configured for use with the modem.

Advanced HotSync® operations

Preparing your computer

There are a few steps you must perform to prepare your computer for a modem HotSync operation. Be sure to perform these steps before you leave your office or home so that your computer is ready to receive a call from your CLIE handheld.

- 1 Check the following to prepare your computer for a modem HotSync operation:
 - The computer modem must be connected to your computer and both the modem and computer are turned on.
 - No communication applications, such as fax or telephony software, are running on the COM port.
 - The computer is disconnected from all online services. This helps to avoid conflicts with the COM port.
- 2 Click the HotSync  icon in the Windows task tray (bottom-right corner of the taskbar) and then select Modem from the shortcut menu.
- 3 Click the HotSync  icon in the Windows task tray again and then select Setup from the shortcut menu.
The Setup dialog box is displayed.
- 4 Click the Modem tab.



Continued on next page

Advanced HotSync® operations

5 Adjust the following options as needed.

- **Serial Port:** Identifies the port for the modem. If you are unsure of the port assignment, look at the Modem Properties in the Windows Control Panel.
- **Speed:** Determines the speed at which data is transferred. Try the “As Fast As Possible” rate first, and then adjust downward if you experience problems. This setting allows the Palm Desktop for CLIE software and your CLIE handheld to find and use the fastest speed.
- **Modem:** Identifies the modem type or manufacturer. Refer to your modem manual or face plate for its type or settings. If you’re not sure of your modem type or your modem doesn’t match any that appear in the list, select Hayes Basic.
- **Setup String:** Identifies the setup string for your particular modem. Not all modems require a setup string. Refer to your modem manual and enter a setup string if recommended by the manufacturer.

6 Click OK.


Preparing your CLIE handheld

Follow the procedures below to prepare your CLIE handheld for a modem HotSync operation.

1 Rotate the Jog Dial navigator to select HotSync and then press the Jog Dial navigator. Or tap the HotSync icon on the Application Launcher screen.

The HotSync dialog box appears.

2 Tap Modem.




Continued on next page

Advanced HotSync® operations


- 3 Tap the arrow ▼ beneath the HotSync icon and then select the modem type from the drop-down list.

Select Sony CLIE Modem.



- 4 Tap the Enter Phone # field.

The Phone Setup dialog box is displayed.



- 5 When using Sony CLIE Modem PEGA-MD700, skip to step 6.

When using another modem or adapter, change the settings as follows:

- ① Enter the telephone number used to access the modem connected to your computer.

If needed, enter a dial prefix (such as “9”) to access an outside line, and then tap the Dial prefix check box. You can enter a comma in the field to introduce a “pause” in the dialing sequence. Each comma equals a two second pause.

- ② If the phone line you’re using for your CLIE handheld has Call Waiting, select the “Disable call waiting” check box to avoid an interruption during the modem HotSync operation.

Continued on next page

Advanced HotSync® operations

- ③ If you want to use a calling card to place the call, select the “Use calling card” check box and enter the calling card number.

Note

If you plan to connect to your company’s dial-in server (network modem) instead of connecting to a computer modem, see “Conducting a HotSync operation via a network” on page 133.

6 Tap OK.

The HotSync screen is displayed again.

To select the conduits for a modem HotSync operation

The Conduit Setup dialog box on your CLIE handheld enables you to define which files and/or applications synchronize during a modem HotSync operation. You can use these settings to minimize the time required to synchronize your data when using a modem.

To change the Conduit Setup for a modem HotSync operation:


- 1 Rotate the Jog Dial navigator to select HotSync and then press the Jog Dial navigator. Or tap the HotSync  icon on the Application Launcher screen.

The HotSync screen appears.

- 2 Tap the Menu  icon.

- 3 Tap Options, and then tap Conduit Setup.

The Conduit Setup screen is displayed.



Continued on next page

Advanced HotSync® operations

- 4 Tap the check boxes to clear the selection of the files and applications that you do not want to synchronize during a modem HotSync operation.

The default setting is to synchronize all files.

Note

Applications that do not have a database (such as games) do not synchronize, even if you select the item in the Conduit Setup dialog box.

- 5 Tap OK.

Performing a HotSync operation via modem

After you prepare your computer and your CLIE handheld, and then select your Conduit Setup options, you are ready to perform a modem HotSync operation.

- 1 Rotate the Jog Dial navigator to select HotSync and then press the Jog Dial navigator. Or tap the HotSync  icon on the Application Launcher screen.

The HotSync screen appears.

- 2 Tap the  icon.

A HotSync operation starts. Wait for the message showing that the HotSync operation is complete.

Advanced HotSync® operations

Conducting a HotSync operation via a network

When you use the Network HotSync application, you can take advantage of the LAN and WAN connectivity available in many office environments. The Network HotSync application enables you to perform a HotSync operation by dialing in to a network or by using a cradle that is connected to any computer on your LAN or WAN (provided that the computer connected to the cradle also has the Network HotSync application installed, your computer is on, and the HotSync Manager is running).

To connect to your company's dial-in server

The Network HotSync application requires the following:

- Your computer has TCP/IP support installed.
- Both your company's network system and its remote access server support TCP/IP.
- You have a remote access account.

Everything you need to connect to your company's dial-in server (network modem) is included in the Palm Desktop for CLIE software and your CLIE handheld. You need to activate certain features, however, on both the Palm Desktop for CLIE software and your CLIE handheld.

Preparing your computer

- 1** Click the HotSync  icon in the Windows task tray and then select Network from the shortcut menu.
- 2** Click the HotSync  icon in the Windows task tray again and then select Setup from the shortcut menu.
The Setup dialog box is displayed.
- 3** Click the Network tab and make sure your user name has a check-mark next to it. If the check-mark is not there, click the check box next to your user name.
- 4** Click OK.

 Continued on next page

Advanced HotSync® operations

- 5 Place your CLIE handheld on the cradle and perform a HotSync operation.

The HotSync operation records network information about your computer onto your CLIE handheld. With this information, your CLIE handheld can locate your computer when you perform a HotSync operation via the network.

Preparing your CLIE handheld


- 1 Rotate the Jog Dial navigator to select HotSync and then press the Jog Dial navigator. Or tap the HotSync  icon on the Application Launcher screen.

The HotSync screen appears.

- 2 Tap the Menu  icon.

- 3 Tap Options, and then tap Modem Sync Prefs.

The Modem Sync Preferences screen is displayed.



- 4 Tap Network.

- 5 Tap OK.


The HotSync screen appears again.

Continued on next page

Advanced HotSync® operations

6 Tap Modem and then Select Service.

The Preferences screen is displayed.



The screenshot shows a 'Preferences' dialog box with a title bar containing 'Preferences' and 'Network'. The dialog contains the following fields and controls:

- Service:** A drop-down menu currently showing 'Aimnet'.
- User Name:** An empty text input field.
- Password:** A text input field containing '-Prompt-'.
- Connection:** A drop-down menu currently showing '-Current-'.
- Phone:** A text input field containing 'Tap to enter phone'.

At the bottom of the dialog are three buttons: 'Done', 'Details...', and 'Connect'.

7 Tap the arrow ▼ next to Service and then select a service from the drop-down list.

8 Tap Done.

9 Tap the Menu icon.

10 Tap Options, and then tap Conduit Setup.

Follow the instructions in “To select the conduits for a modem HotSync operation” on page 131.

Advanced HotSync® operations

Importing data from a Windows application

If you have data stored in Windows computer applications such as spreadsheets and databases, you can transfer that data to your CLIE handheld.

Importable file formats

Save data in one of the file formats listed below, import it into the Palm Desktop for CLIE software, and then perform a HotSync operation to transfer the data to your CLIE handheld.

The Palm Desktop for CLIE software can import data in the following file formats:

- Comma delimited (*.csv, *.txt): Address Book and Memo Pad only
- Tab delimited (*.tab, *.tsv, *.txt): Address Book and Memo Pad only
- CSV (Lotus Organizer 2.x/97 Mapping): Address Book only
- Date Book archive (*.dba)
- Address Book archive (*.aba)
- To Do archive (*.tda)
- Memo Pad archive (*.mpa)

Archive formats can only be used with the Palm Desktop for CLIE software. Use the archive file formats to share information with other people who use a Palm OS® platform handheld or to create a copy of your important the Palm Desktop for CLIE software information.

Advanced HotSync® operations

Importing data

- 1** Start the Palm Desktop for CLIE software.
- 2** Click the application into which you want to import data.
- 3** If you are importing records that contain a field with category names, select **All** in the **Category** box.
Be sure that the same categories that appear in the imported file also exist in the application. If the categories do not exist, create them now; otherwise, the records will be imported into the **Unfiled** category.
- 4** Click **Import from the File** menu.
The **Import** dialog box is displayed.
- 5** Select the file you want to import.
- 6** Click **Open**.
- 7** To import data into the correct Palm Desktop for CLIE fields, drag the fields in the left-hand column so that they are opposite to the corresponding imported fields on the right.
- 8** Clear the check box for the field that you do not want to import.
- 9** Click **OK**.
The imported data is highlighted in the application.
- 10** To add the imported data to your CLIE handheld, perform a **HotSync** operation.

See the Palm Desktop for CLIE online Help for more information on importing and exporting data.

Advanced HotSync® operations

Synchronizing with external data (File Link)

The File Link feature allows you to import Address Book and Memo Pad information onto your CLIE handheld from a separate external file such as a company phone list. HotSync Manager stores the data in a separate category on your Palm Desktop for CLIE software and your CLIE handheld. You can set the File Link feature to check for changes to the external file when you perform a HotSync operation.

With File Link, you can import data stored in any of the following file formats:

- Comma-delimited (*.csv)
- Palm Desktop for CLIE software's Memo Pad archive (*.mpa)
- Palm Desktop for CLIE software's Address Book archive (*.aba)
- Text (*.txt)

For information on how to set up File Link, see the Palm Desktop for CLIE online help.

Chapter 4

Communicating using your Sony CLIE Handheld

This chapter describes how to communicate with another Palm OS® PDA via the infrared communications port or “Memory Stick®” media. It also explains how to handle “Memory Stick” media and how to use the MS Gate application software for managing the data in “Memory Stick” media.


Contents

Beaming between your Sony CLIE Handheld and another Palm OS® PDA	140
What you can do with beaming	140
Beaming information	141
Receiving beamed information	142
Tips on beaming information	142
Using “Memory Stick®” media	143
What is “Memory Stick®” media?	143
Inserting and removing “Memory Stick” media	144
Protecting the data in “Memory Stick” media	146
Starting an application automatically when “Memory Stick” media is inserted	146
Formatting “Memory Stick” media	147
Exchanging data via “Memory Stick®” media	149
Starting Memory Stick Gate (MS Gate)	149
Creating the default folder in “Memory Stick” media	152
Copying your CLIE handheld data to “Memory Stick” media	153
Copying data in “Memory Stick” media to your CLIE handheld	155
Deleting data in “Memory Stick” media	157
Using the MS Gate menus	159
How to read the online manual	160

Beaming between your Sony CLIE Handheld and another Palm OS® PDA

What you can do with beaming

Your Sony handheld is equipped with an IR (infrared) port that you can use to beam information to another Palm OS® PDA device that's close by and also has an IR port. The IR port is located at the top of your CLIE handheld, behind the small dark shield.



You can beam the following information between your CLIE handheld and another Palm OS PDA:

- The record currently displayed in Address Book, Date Book, To Do List, or Memo Pad.
- All records of the category currently displayed in Address Book, Date Book, To Do List, or Memo Pad.
- A special Address Book record that you designate as your business card.
- An application installed in RAM memory.

Note


Some applications are protected and cannot be beamed, as indicated by a lock icon to the side of applications.

Beaming between your Sony CLIE Handheld and another Palm OS® PDA

Beaming information

You can beam a record, business card, or category of records between your CLIE handheld and another Palm OS PDA.

- 1** Locate the record, business card, or category you want to beam.
- 2** Tap the Menu  icon.
- 3** Tap one of the following from the Record menu:
 - The Beam command for an individual record
 - In Address Book only: Beam Business Card
 - Beam Category
- 4** When the Beam dialog box appears, point the IR port directly at the IR port of the receiving handheld.



Tip

For best results, your CLIE handheld and another Palm OS PDA should be 4 to 8 inches (approximately 10 to 20 centimeters) apart, and the path between the two handhelds must be clear of obstacles and shielded from fluorescent lighting. Beaming distance to other Palm OS PDA handhelds may be different.

- 5** Wait for the Beam dialog box to indicate that the transfer is complete before you continue working on your CLIE handheld.

Beaming between your Sony CLIE Handheld and another Palm OS® PDA

Receiving beamed information

- 1 Turn on your CLIE handheld.
- 2 Point the IR port directly at the IR port of the other Palm OS PDA handheld transmitting the data.
The Beam dialog box is displayed. Beaming data starts.
You can select the category in which you save the data in a dialog box.
- 3 Tap Yes.
The data is saved to the unfiled category.

Note

If Beam Receive in the Preferences menu is set to *Off*, you cannot receive data using the beaming feature. Before beaming data, make sure to set Beam Receive to *On*.

Tips on beaming information

- Incoming data or application should be placed in the Unfiled category.
- You can press the Address Book  button for about two seconds to beam your business card.
- You can use Graffiti to beam the current entry (/ then , or / and then tap ).

Using “Memory Stick®” media

What is “Memory Stick®” media?

“Memory Stick®” media is a new compact, portable and versatile Integrated Circuit recording medium with a data capacity that exceeds a floppy disk. “Memory Stick” media is specially designed for exchanging and sharing digital data among “Memory Stick” media compatible products such as a digital video camera. Because it is removable, “Memory Stick” media can also be used for external data storage.

“Memory Stick” media allows you to exchange data between your CLIE handheld and your computer or a digital camera that supports “Memory Stick” media. To exchange data via “Memory Stick” media, your CLIE handheld uses the supplied Memory Stick Gate (MS Gate) software.

Types of “Memory Stick” media

There are two types of “Memory Stick” media:

- “MagicGate Memory Stick” media equipped with “MagicGate” copyright protection technology. “MagicGate Memory Stick” media is distinguished by the  logo.
- “Memory Stick” media that is not equipped with “MagicGate” copyright protection technology.

Your CLIE handheld supports both types of “Memory Stick” media.

To play back OpenMG audio files, however, make sure to use “MagicGate Memory Stick” media.

To play back MP3 files, you can use a purple regular “Memory Stick” media. (You can also use “MagicGate Memory Stick” media.)

What is “MagicGate”?

“MagicGate” is a copyright protection technology for “MagicGate Memory Stick” media and compliant products, such as your CLIE handheld. Authentication ensures that protected content is transferred only between compliant devices and “MagicGate Memory Stick” media, and that protected content is recorded and transferred in an encoded format to prevent unauthorized copying or playback.

Note on using “MagicGate Memory Stick” media


If you use MS Gate or Windows® Explorer to copy a protected file onto a “MagicGate Memory Stick” media or if you handle a folder containing a protected file, the file may be disabled. To handle the copyright-protected file, use a “MagicGate” compliant application such as OpenMG Jukebox.

Using “Memory Stick®” media

Inserting and removing “Memory Stick” media

Insert “Memory Stick” media into the “Memory Stick” slot as illustrated below.

The “Memory Stick” indicator lights in orange while your CLIE handheld is accessing “Memory Stick” media.




Note

Insert “Memory Stick” media in the right direction. If “Memory Stick” media is forced in the wrong way, it may be damaged.


To remove “Memory Stick” media

Make sure that your CLIE handheld is not writing to or reading data from “Memory Stick” media.

Push “Memory Stick” media gently into the slot and then release it so that “Memory Stick” media pops out. Then pull it out from your CLIE handheld.



Push “Memory Stick” media in.



Pull “Memory Stick” media out.

Using “Memory Stick®” media

Notes on using “Memory Stick” media

When you use “Memory Stick” media, follow these precautions:

- Avoid touching the terminal of “Memory Stick” media or contacting it with a metal object.
- Do not drop, bend, or submit “Memory Stick” media to external shock.
- Do not disassemble or modify “Memory Stick” media.
- Avoid getting liquids on “Memory Stick” media.
- Avoid using or storing “Memory Stick” media in a location subject to:
 - extremely high temperature such as the hot inside of a car, the outdoors exposed to direct sunlight, or near a heater.
 - direct sunlight
 - high humidity
 - corrosive substances
 - excessive dust
 - magnetic fields
- When storing and carrying “Memory Stick” media, keep it in its original case to ensure protection of important data.
- Save a backup for important data.
- Avoid removing “Memory Stick” media from the insertion slot while data is being written or read.
- To avoid damaging or erasing data, do not
 - release “Memory Stick” media or unplug the AC power adapter while formatting, or reading or writing data.
 - use “Memory Stick” media in a location subject to static electricity or electric noise.
- If the battery of your CLIE handheld is running out, an error message is displayed and you cannot exchange data with “Memory Stick” media. If this occurs, connect the AC power adapter or fully charge your CLIE handheld.
- Use the MS Gate software to format “Memory Stick” media you use in your CLIE handheld. If you format it using another application, further operation with your CLIE handheld is not guaranteed.
- If you insert “Memory Stick” media that has been formatted by another application, a message prompting you to format it is displayed. To use “Memory Stick” media in your CLIE handheld, follow the instructions to format it. Note, however, that all stored data will be erased.

Using “Memory Stick®” media

Protecting the data in “Memory Stick” media


To prevent accidental erasure of important data, you can use the write protect tab of “Memory Stick” media. Slide the tab to the left or right to enable or disable writing to “Memory Stick” media.

Write enable position

Slide the tab to the left to select the write enable position. You can write and read the data in “Memory Stick” media.

Write protect position

Slide the tab to the right. You can just view the data in “Memory Stick” media. Select the write protect position when you do not want to overwrite or delete the data in the inserted “Memory Stick” media.



Starting an application automatically when “Memory Stick” media is inserted

The Memory Stick Autorun (MS Autorun) allows you to start a specified application automatically when “Memory Stick” media is inserted into your CLIE handheld. You can select your favorite application as the auto-run application. If you enjoy music, for example, select Audio Player. Or if you like watching still images, set PictureGear™ Pocket to start automatically. See the supplied Add-On Application Guide for details.


Using “Memory Stick®” media

Formatting “Memory Stick” media

Commercially available “Memory Stick” media is already formatted and you can use it as soon as you buy it. Follow the procedures below if you need to format your “Memory Stick” media again:

- 1 Rotate the Jog Dial™ navigator to select MS Gate and press the Jog Dial navigator. Or tap the MS Gate  icon on the Application Launcher screen.

MS Gate starts up.



- 2 Tap the Menu  icon.
The Menu screen appears.
- 3 Tap Options, and then Format.
The confirmation message appears.



- 4 Tap OK.
Formatting starts.

To cancel formatting

Tap Cancel in step 3.

Continued on next page

Using “Memory Stick®” media

What is formatting?

Formatting defines the recording format for your “Memory Stick” media so that you can access data with your CLIE handheld.

Notes

- If formatted, all the data previously recorded in “Memory Stick” media will be erased. Make sure to check the data before formatting so that you do not delete important data.
- To use “Memory Stick” media on your CLIE handheld, format it in your CLIE handheld. You may not be able to write or read properly on “Memory Stick” media formatted by the computer.
- If you remove or insert “Memory Stick” media during initialization, your “Memory Stick” media is not recognized by your computer. In this case, remove “Memory Stick” media, reinstall it, and then start formatting again.

Exchanging data via “Memory Stick®” media

Starting Memory Stick Gate (MS Gate)


MS Gate allows you to copy, move, or delete data in “Memory Stick®” media and in your CLIE handheld.

Rotate the Jog Dial™ navigator to select MS Gate and then press the Jog Dial navigator. Or tap the MS Gate  icon on the Application Launcher screen.

MS Gate starts up and data lists appear on your CLIE handheld screen.

When displaying the contents of your CLIE handheld

Once you create the default folder, the “PALM/PROGRAMS/MSFILES” folder is displayed even when the Internal is selected.



Tap this icon to switch the view between your CLIE handheld and “Memory Stick” media.

Lock  icon.

Tap here to switch the view.
size : File size
creator: Creator ID of the file
type : File type
version: Version of the file
none : no items displayed

Tap this icon to switch the view between your CLIE handheld and “Memory Stick” media.

Displays the files which belong to the same creator (ID) as one grouped item.

Tap this icon to display or hide the contents.

Tap this icon to sort in ascending order or in descending order.


Continued on next page

Exchanging data via “Memory Stick®” media

When displaying the contents of “Memory Stick” media

The following icons with explanations are displayed only when you view the contents of “Memory Stick” media. For the other icons, see “When displaying the contents of your CLIE handheld” (page 149).

: Tap this icon to display upper folder.



: Tap this icon to display the contents of the folder.

Tap here to display “file name” to show the file name with PC file extensions.

Exchanging data via “Memory Stick®” media

Notes on moving or copying data using MS Gate

In some cases when you move or copy a specific file using the MS Gate software, a CLIE application may not function properly. Sony is not liable for any trouble with applications or data that arises out of your deletion or moving of a file.

Do not move or delete the following files:

- Saved Preference: Saves the final operation status or settings for various applications.
- Unsaved Preference: Saves the settings of various applications or user information of your CLIE handheld. When this file is deleted, you may not be able to synchronize correct information.
- NetworkDB: Saves network settings. When this file is deleted, network connection is disabled.
- AddressDB: Saves the database for Address Book.*
- DatebookDB: Saves the database for Date Book.*
- MemoDB: Saves the database for Memo Pad.*
- ExpenseDB: Saves the database for Expense.*
- MailDB: Saves the database for Mail.*
- ToDoDB: Saves the database for To Do List.*

* These database files can be copied to “Memory Stick” media for backup. If you copy them back to your CLIE handheld, the identical files in your CLIE handheld will be overwritten with the information at the time of backup. Note that any added or edited data in your CLIE handheld after the backup will be erased.

Exchanging data via “Memory Stick®” media

Creating the default folder in “Memory Stick” media


When using either of the following “Memory Stick” media, you should create the default folder in “Memory Stick” media.

- “Memory Stick” media to be used in MS Gate Ver.2.0 for the first time
- “Memory Stick” media just formatted

The “default folder” stands for the standard working folder where MS Gate Ver.2.0 reads and writes data. A folder named “PALM/PROGRAMS/MSFILES” is created in “Memory Stick” media.

- 1** Insert “Memory Stick” media into your CLIE handheld.
- 2** Rotate the Jog Dial navigator to select MS Gate and then press the Jog Dial navigator. Or tap the MS Gate  icon on the Application Launcher screen.

MS Gate starts. The data in your CLIE handheld is listed.



- 3** Tap the Menu  icon.
The Menu screen appears.
- 4** Tap Tools, and then Create Default Folder.
The default folder (“ /PALM/PROGRAMS/MSFILES”) is created in “Memory Stick” media.

Exchanging data via “Memory Stick®” media

Copying your CLIE handheld data to “Memory Stick” media


MS Gate allows you to save the data inside your CLIE handheld onto “Memory Stick” media.

Notes

- Since data copying consumes a lot of power, you cannot use “Memory Stick” media when your CLIE handheld is short of battery power. Connect the AC adapter.
- If you receive infrared communication while copying data, the copying will be terminated. Do not allow infrared communication while copying data.

- 1 Insert “Memory Stick” media into your CLIE handheld.
- 2 Rotate the Jog Dial navigator to select MS Gate and then press the Jog Dial navigator. Or tap the MS Gate  icon on the Application Launcher screen.

MS Gate starts. The data in your CLIE handheld is listed.



- 3 Tap to select the data you want to copy to “Memory Stick” media.

Tip

You can select multiple files.

Note

You cannot copy data marked with a lock  icon.

Continued on next page

Exchanging data via “Memory Stick®” media

4 Tap COPY.

The Copy File dialog box is displayed.



5 Tap OK.

The data selected in step 3 is copied to the default folder (“/PALM/PROGRAMS/MSFILES”) in “Memory Stick” media.

To copy all the data at once

Tap Select All in step 3.

To cancel the selection

- To cancel all the selections, tap Clear All.
- To clear the selection of individual selected items only, tap them one at a time.

To change the destination folder

Tap the arrow ▼ in the upper right corner to select MS from the drop-down list. The contents of “Memory Stick” media are listed.

Tap  or  to select the destination folder, so that the folder display changes and you can specify the destination folder.

You can only select a folder under the “PALM/PROGRAMS” folder. The other folders cannot be selected as destination.

Moving your CLIE handheld data to “Memory Stick” media

If your CLIE handheld is running out memory space, it is a good idea to move the data from your CLIE handheld to “Memory Stick” media.

In step 4, tap Move.

The data on your CLIE handheld is deleted after saved on “Memory Stick” media.

Note

When low battery error message is displayed while you are copying or moving data in your CLIE handheld to “Memory Stick” media, data copying or moving may fail, leaving invalid files in “Memory Stick” media. If this occurs, charge your CLIE handheld and try copying or moving again. When an overwrite confirm message appears, tap Yes or Yes to all.

Exchanging data via “Memory Stick®” media

Copying data in “Memory Stick” media to your CLIE handheld

MS Gate allows you to copy the data saved in “Memory Stick” media to your CLIE handheld.

Note


Make sure your CLIE handheld has enough space before copying.

- 1 Insert “Memory Stick” media into your CLIE handheld.
- 2 Rotate the Jog Dial navigator to select MS Gate and then press the Jog Dial navigator. Or tap the MS Gate  icon on the Application Launcher screen.

MS Gate starts. The data in your CLIE handheld is listed.

- 3 Press the Jog Dial navigator to select MS.

You can also tap the arrow ▼ in the upper right corner to select MS from the drop-down list.



You can also select MS by tapping .

The data in the default folder (“/PALM/PROGRAMS/MSFILES”) in “Memory Stick” media is listed.

- 4 Tap to select the data you want to copy to your CLIE handheld.
- 5 Tap COPY.
The Copy File dialog box is displayed.
- 6 Tap OK.

The data selected in step 4 is copied to your CLIE handheld.

Continued on next page

Exchanging data via “Memory Stick®” media

To copy all the data at once

Tap Select All in step 4.

To cancel the selection

- To cancel all the selections, tap Clear All.
- To clear the selection of individual selected items only, tap them one at a time.

To change the folder to be copied

Tap  or  to select the folder that you want to copy, so that the folder display changes and you can specify a folder to be copied.

You can only select a folder under the “PALM/PROGRAMS” folder. The other folders cannot be selected.

To rename the file or folder name

Select the file or folder that you want to rename, and then tap the Menu  icon. Tap Tools and then Rename. Rename the file or folder in the following dialog box.



Moving data in “Memory Stick” media to your CLIE handheld

You can also move data from “Memory Stick” media to your CLIE handheld.

Tap MOVE in step 5.

The data in “Memory Stick” media is deleted after being saved in your CLIE handheld.

Note

Some data such as those copied from “Memory Stick” media to your CLIE handheld will not be backed up during the next HotSync operation.

Exchanging data via “Memory Stick®” media


Deleting data in “Memory Stick” media

MS Gate allows you to delete unnecessary data from “Memory Stick” media.

- 1 Insert “Memory Stick” media in your CLIE handheld.
- 2 Rotate the Jog Dial navigator to select MS Gate and then press the Jog Dial navigator. Or tap the MS Gate  icon on the Application Launcher screen.

MS Gate starts. The data in your CLIE handheld is listed.

- 3 Press the Jog Dial navigator to select MS. You can also tap the arrow ▼ in the upper right corner to select MS from the drop-down list.



You can also select MS by tapping .

The data in the “/PALM/PROGRAMS/MSFILES” folder of “Memory Stick” media is listed.

- 4 Tap to select the data that you want to delete.
- 5 Tap DELETE.

The Delete File dialog box is displayed.



Continued on next page

Exchanging data via “Memory Stick®” media

6 Tap OK.

The data selected in step 4 is deleted from “Memory Stick” media.

To delete all data at once

Tap Select All in step 4.

To cancel the selection

- To cancel all the selections, tap Clear All.
- To clear the selection of individual selected items only, tap them one at a time.

To change the folder to be deleted

Tap  or  to select the folder that you want to delete, so that the folder display changes and you can specify a folder to be deleted.

You can only select a folder under the “PALM/PROGRAMS” folder. The other folders cannot be selected.

Exchanging data via “Memory Stick®” media

Using the MS Gate menus

MS Gate menu commands allow you to exchange data between your CLIE handheld and “Memory Stick” media.

Tools menus

The menu items differ depending on the screen being displayed.

Select All	Selects all the data displayed in the selected tab.
Clear All	Cancels the selection of the data.
Move	Moves the selected data to your CLIE handheld or “Memory Stick” media. The Move files screen appears.
Copy	Copies the selected data to your CLIE handheld or “Memory Stick” media. The Copy files screen appears.
Delete	Deletes the selected data from your CLIE handheld or “Memory Stick” media. The Delete files screen appears.
Rename	Changes the name of the selected file or folder of “Memory Stick” media.
Create Folder	Creates a folder in the current folder.
Create Default Folder	Creates the default folder (“/PALM/PROGRAMS/MSFILES”) in “Memory Stick” media.
Change to Default Folder	Changes the current folder as default folder.

Options menus

Format	Formats “Memory Stick” media inserted in your CLIE handheld.
Media Information	Displays the memory information of “Memory Stick” media.
About MS Gate	Shows the version information for MS Gate.

Exchanging data via “Memory Stick®” media

How to read the online manual

Detailed information on MS Gate software is provided in the online manual on the supplied CD-ROM.

To see the online manual, the Adobe Acrobat Reader® software must be installed on your computer.

- 1** Insert the Installation CD-ROM into your computer’s CD-ROM drive.

The installation launcher window is displayed.

- 2** Click Manuals.

- 3** Double-click MSGate.pdf.

The online manual appears.

If the Acrobat Reader software is not installed

- 1** Insert the Installation CD-ROM into your computer’s CD-ROM drive.

The installation launcher window is displayed.

- 2** Click Exit to close the installation launcher window.

- 3** Double-click the My computer icon on the Windows desktop.

- 4** Right-click the CD-ROM drive icon, and then click Open from the shortcut menu.

- 5** Double-click the Acrobat folder.

- 6** Double-click Setup.exe to install the Acrobat Reader onto your computer.

Follow the instructions onscreen to finish installation.

Chapter 5

Customizing your Sony CLIE Handheld (Preferences)

This chapter describes how to customize your CLIE handheld by changing the Preferences settings.

Contents

 What you can do with Preferences	162
Changing the Buttons preferences	164
Assigning applications to buttons	164
Changing the full-screen pen stroke activities	165
Assigning applications to HotSync® buttons	166
Changing the Jog Dial™ navigator preferences	167
Setting the display format of the time, date, and numbers (Formats)	168
Selecting a country default	168
Selecting the time, date, and numbers formats	169
Setting the General preferences	170
Setting the time	170
Setting the date	171
Setting the automatic shut-off time	172
Setting sounds	173
Turning on or off the Beam Receive feature	174
Entering owner information	175
Creating Graffiti® ShortCuts	176
Setting the High Resolution Assist function	178



What you can do with Preferences

The Preferences screen enables you to customize the configuration options on your CLIE handheld.

- **Buttons**

Assign different applications to the buttons on the front panel of your CLIE handheld and the HotSync® button on the cradle, and reassign the full-screen pen stroke command.

- **Connection**

Configure serial, modem, and infrared communication settings.

- **Digitizer**

Calibrate the screen on your CLIE handheld. The same digitizer calibration screen is displayed when you start your CLIE handheld for the first time. You can recalibrate your screen after a hard reset or if you find that “tapping” does not work as expected. For details, see “Step 2: Turning on your Sony CLIE Handheld for the first time” in the Read This First manual.

- **Formats**

Set the country default and the formats for dates, times, calendar, and numbers.

- **General**

Set the current date and time, the auto shut-off interval, the “Stay on in Cradle” feature, the Beam Receive feature, system, alarm, and game sounds.

- **Jog**

Enable or disable the JogAssist feature.

- **Network**

Configure your CLIE handheld for use with a network.

- **Owner**

Assign your name, phone number, and other owner information.

- **ShortCuts**

Define a list of Graffiti® abbreviations.




What you can do with Preferences


Viewing Preference

- 1 Rotate the Jog Dial™ navigator to select Prefs and then press the Jog Dial navigator. Or tap the Prefs  icon on the Application Launcher screen.

The Preferences screen appears.



- 2 Tap the arrow ▼ in the upper right on the screen and then select the Preferences screen you want to view from the drop-down list.




Changing the Buttons preferences

Assigning applications to buttons

The Buttons Preferences screen enables you to assign different applications to the buttons on the front panel of your CLIE handheld.

For example, you can assign the To Do List button to start Expense.



- 1 Tap Buttons from the drop-down list on the Preferences screen.

The Buttons Preferences screen is displayed.



- 2 Tap the arrow ▼ next to a button and then tap the application that you want to assign to the button.

To launch the original applications

When you have assigned another application to the button, you can start the original application using the Application Launcher.


To reset to the default settings

Tap Default in step 2. All application buttons are reset to their factory settings.

Changing the Buttons preferences


Changing the full-screen pen stroke activities

The Buttons Preferences screen enables you to change the assignment of the full-screen pen stroke. By default, the full-screen pen stroke activates the Graffiti® Help.



Drag the stylus from the bottom of the writing area to the top on the screen.

- 1 Tap Buttons from the drop-down list on the Preferences screen. The Buttons Preferences screen is displayed.
- 2 Tap Pen.
- 3 Tap the arrow ▼ and then select one of the following settings for the full-screen pen stroke.



- **Frontlight:** Turns on the frontlight of your CLIE handheld without using the POWER button.
- **Brightness:** Opens the brightness adjustment screen.
- **Keyboard:** Opens the onscreen keyboard for entering text.
- **Graffiti Help:** Opens a series of screens that show the complete Graffiti character set.
- **Turn Off & Lock:** Turns off and locks your CLIE handheld. To lock your CLIE handheld, assign a password. When locked, you need to enter the password to use your CLIE handheld.
- **Beam Data:** Beams the current record to another Palm OS® PDA.

- 4 Tap OK.

Changing the Buttons preferences

Assigning applications to HotSync® buttons

The Buttons Preferences screen also enables you to assign different applications to the HotSync® buttons on the cradle and the modem.

- 1 Tap Buttons from the drop-down list on the Preferences screen.


The Buttons Preferences screen is displayed.

- 2 Tap HotSync.

The HotSync Buttons dialog box appears.

- 3 Tap the arrow ▼ next to each button and then select the application you want to assign to the button.

The HotSync button assignment is changed.



- 4 Tap OK.

Any changes that you make in the HotSync Buttons screen become effective immediately. You can activate the selected application by pressing the HotSync button.

Changing the Jog Dial™ navigator preferences

The Jog Preferences screen enables you to change the Jog Dial™ navigator and BACK button functions. With the JogAssist feature, you can use the Jog Dial navigator to operate a third-party application that is not designed to use Jog Dial navigator operations.

You can use the Jog Dial navigator and the BACK button to:


- Scroll the screen with the Jog Dial navigator.
- Select an item from a pop-up list with the Jog Dial navigator.
- Move back and forth between screens with the BACK button.

You can also change the BACK button function so that you can turn your CLIE handheld on or off by keeping this pressed.

Notes

- The functions activated by the JogAssist feature differ depending on the application you use.
- In some applications with the Jog Dial navigator mark, part of the functions may change when the JogAssist feature is enabled.
- The JogAssist feature does not support menu operations.

- 1** Tap Jog from the drop-down list on the Preferences screen. The Jog Preferences screen is displayed.



- 2** To enable the JogAssist function, select Use JogAssist.
- 3** In order to set to turn off the power by keeping the BACK button pressed, select Enable Power Control. The Jog Dial navigator and BACK button functions change.

On the default settings

Use JogAssist is selected () and Enable Power Control is not selected ()

Setting the display format of the time, date, and numbers (Formats)

The Formats Preferences screen enables you to set the country default, and the display format of dates, times, and numbers on your CLIE handheld.


Selecting a country default

When you select the country where you use your CLIE handheld, the display format of the time, date, the week start day, and numbers is adjusted. For example, in England, time is expressed using a 24-hour clock; in the United States, time is expressed using a 12-hour clock with an AM or PM suffix.

All your CLIE applications use the Country default settings. However, you can customize your own settings for time, date, week start day, or numbers.

- 1 Tap Formats from the drop-down list on the Preferences screen.

The Formats Preferences screen is displayed.



The screenshot shows the 'Preferences' screen with a dropdown menu set to 'Formats'. The 'Preset to' dropdown is set to 'United States'. Below it, the 'Time' is set to 'HH:MM am/pm' with a sample time of '10:03 pm'. The 'Date' is set to 'M/D/Y' with a sample date of '3/20/01' and 'Mar 20, 2001'. The 'Week starts' is set to 'Sunday'. The 'Numbers' are set to '1,000.00'.

- 2 Tap the arrow ▼ next to "Preset to" and then select a country name.



The screenshot shows the 'Preferences' screen with the 'Preset to' dropdown menu open, displaying a list of countries: Mexico, Netherlands, New Zealand, Norway, P.R.C., Philippines, Singapore, Spain, Sweden, Switzerland, Taiwan, Thailand, United Kingdom, and United States. The 'United States' option is highlighted at the bottom of the list.


- 3 Tap OK.

Setting the display format of the time, date, and numbers (Formats)

Selecting the time, date, and numbers formats

You can select the desired formats for the time, date, week start day, and numbers. The selected formats apply to all your CLIE applications.

- 1 On the Formats Preferences screen, tap the arrow ▼ next to Time and then select the desired format from the drop-down list.



- 2 Tap the arrow ▼ next to Date and then select the desired format from the drop-down list.
- 3 Tap the arrow ▼ next to Week starts and then select whether you want the first day of the week to be Sunday or Monday. This setting controls the Day, Week, Month, and Agenda views in Date Book and all other aspects of your CLIE handheld that display a calendar.
- 4 Tap the arrow ▼ next to Numbers and then select formats for the decimal point and thousands separator.


Setting the General preferences

The General Preferences screen enables you to set the time, date, auto shut off interval, and sounds for your CLIE handheld.

Setting the time


- 1 Tap General from the drop-down list on the Preferences screen.

The General Preferences screen is displayed.



- 2 Tap Set Time.

The Set Time screen appears.



- 3 Tap the arrow ▼ or ▲ to set the hour.
- 4 Tap the minute box and then tap the arrow ▼ or ▲ to set the minute.
- 5 Tap AM or PM.
- 6 Tap OK.

Setting the General preferences


Setting the date

- 1 Tap General from the drop-down list on the Preferences screen.

The General Preferences screen is displayed.

- 2 Tap Set Date.

The Set Date screen appears.



- 3 Tap the arrow ◀ or ▶ beside the year at the top of the screen to set the year.
- 4 Tap the current month.
- 5 Tap the current date.

Setting the General preferences

Setting the automatic shut-off time

Your CLIE handheld has an automatic shut-off feature that turns off the power after a period of inactivity. This feature helps conserve battery power in case you forget to turn off your CLIE handheld. If you find that your CLIE handheld shuts itself off too early or too late, you can increase or decrease the time setting for the automatic shut-off feature.


By default, your CLIE handheld will turn off after two minutes of inactivity and will be on as long as it is connected to the cradle.

- 1 Tap General from the drop-down list on the Preferences screen.

The General Preferences screen is displayed.

- 2 Tap the arrow ▼ next to Auto-off after and then select the desired time setting for the automatic shut-off feature.

You can select 30 seconds, 1 minute, 2 minutes, or 3 minutes.



- 3 If you want to leave your CLIE handheld turned on while it is connected to the cradle, make sure that the check box next to "Stay on in Cradle" is selected. To turn it off automatically, clear the check box.

Setting the General preferences

Setting sounds


Your CLIE handheld uses a variety of sounds. The System, Alarm, and Game Sound settings enable you to turn the sounds on or off, and to adjust the volume level.

- 1 Tap General from the drop-down list on the Preferences screen.

The General Preferences screen is displayed.

- 2 Tap the arrow ▼ next to System Sound and then select the desired sound level or Off from the drop-down list.

When you turn the System Sound off, you also turn off the “chime” tones associated with the HotSync operation.



- 3 Tap the arrow ▼ next to Alarm Sound and then select the desired sound level from the drop-down list.

- 4 Tap the arrow ▼ next to Game Sound and then select the desired sound level or Off from the drop-down list.

The Game Sound setting works only with the games that are programmed to respond to this setting.

Setting the General preferences


Turning on or off the Beam Receive feature

You can choose to turn off the Beam Receive feature. This prohibits anyone from beaming information to your CLIE handheld. It also results in a slight saving of battery power. By default, the Beam Receive is set to On.

- 1 Tap General from the drop-down list on the Preferences screen.

The General Preferences screen is displayed.

- 2 Tap the arrow ▼ next to Beam Receive and then select On or Off from the drop-down list.



- **On:** Enables the Beam Receive feature.
- **Off:** Disables the Beam Receive feature.


Entering owner information

The Owner Preferences screen enables you to record a name, company name, or phone number, or any other information that you want to associate with your CLIE handheld.

If you use the Security application to lock your CLIE handheld with a password, the information that you enter in the Owner Preferences screen appears the next time you turn on your CLIE handheld.

1 Tap Owner from the drop-down list on the Preferences screen.

The Owner Preferences screen is displayed.



2 Enter your owner information.

If you enter more text than can fit on one screen, a scroll bar appears at the right side of the screen.

To unlock the Owner Preferences screen

If you assigned a password in the Security application, the information in the Owner Preferences screen cannot be changed. In this case, an Unlock button is displayed at the bottom of the screen.

1 Tap Unlock.

The Unlock Message dialog box appears.



2 Enter your current password (the one you entered in the Security application) and then tap OK.

Creating Graffiti® ShortCuts

The ShortCuts Preferences screen enables you to define abbreviations (ShortCuts) for entering text with Graffiti® strokes. You can create a ShortCut for any words, letters, or numbers. All ShortCuts you create appear on the list in the ShortCut Preferences screen. All the ShortCuts are available in any of your CLIE applications and are backed up on your computer when you perform a HotSync operation. See “Using Graffiti® writing to enter data” on page 13 for more information on the use of ShortCuts.


- 1** Tap ShortCut from the drop-down list on the Preferences screen.

The ShortCut Preferences screen is displayed.



- 2** Tap New.

The ShortCut Entry screen is displayed.



- 3** On the ShortCut name line, enter the letters you want to use to activate the ShortCut.
- 4** Tap the ShortCut Text area and then enter the text that you want to appear when you write the ShortCut characters.
- 5** Tap OK.

Creating Graffiti® ShortCuts

To Edit a ShortCut

- 1** Tap the ShortCut you want to edit in the ShortCuts list and then tap Edit.
- 2** Make the changes you want and then tap OK.

To Delete a ShortCut


If you no longer need a ShortCut, you can delete it from the list of ShortCuts.

- 1** Tap the ShortCut you want to delete in the ShortCuts list and then tap Delete.
The confirmation dialog box is displayed.
- 2** Tap Yes.


Setting the High Resolution Assist function

The High Resolution Assist function enables the high resolution display of an application that does not support the high resolution mode. To use the High Resolution Assist feature, follow the instructions in “Recommendation for installing the Up-date file” in the Read This First manual and make sure that you have installed the Up-date file contained in the supplied CD-ROM into your CLIE handheld.

- 1** Tap HiRes from the drop-down list on the Preferences screen. The HiRes Preferences screen is displayed.
- 2** To enable the High Resolution Assist function, select Enable High Resolution Assist.



- 3** Select the application(s) that you do not want to display in high resolution mode in the list box.



Note

In step 3, check an application when the following occurs in the high resolution mode:

- Performances are largely deteriorated (ex. game).
- Display is divided into two, characters are distorted, or other operational irregularities occur.

Chapter 6

Additional information

This chapter describes how to upgrade your CLIE handheld, as well as some precautions, troubleshooting information, and other technical information about your CLIE handheld.

Contents

Backing up data of your Sony CLIE Handheld	180
Backing up data in your computer using a HotSync operation	180
Backing up your CLIE handheld data using “Memory Stick” media	181
Using data of another Sony CLIE Handheld	183
Using the Palm Desktop for CLIE software to transfer data	183
Using “Memory Stick” media to transfer data	185
Precautions	187
Notes on use	187
Battery considerations	188
Troubleshooting—Frequently Asked Questions	190
If you cannot perform a HotSync operation	203
Getting Help	207
Specifications	208
Limited Warranty Statement	209
Index	213

Backing up data of your Sony CLIE Handheld

You can save a backup copy of your CLIE handheld with either of the following two methods:

- Backing up data using a HotSync® operation
- Backing up data using “Memory Stick®” media

Backing up data in your computer using a HotSync operation

By default, you can backup the following data in your computer using a HotSync operation:

- Memo Pad data files
- Address Book data files
- To Do List data files
- Date Book data files
- Expense data files
- Preferences data files
- Applications files that have been installed using a HotSync operation
- User information files when you perform a HotSync operation

During the next HotSync operation, the backup data is compared with the data in your computer, and the newer one becomes effective.

If you perform a hard reset, all records and entries stored in your CLIE handheld are erased and reset to the initial status. If you save a backup of your CLIE handheld data, you can restore any data previously synchronized with your computer during the next HotSync operation.

Notes

- Some applications are not designed to be backed up. Therefore, you may not be able to restore some applications and data. We recommend you to re-install the application again.
- If you change settings in the Change HotSync Action dialog box, you may not be able to save a backup. You cannot back up or restore data for the application if you select another option than “Synchronize the files.” For details, see “Customizing HotSync application settings (Conduit)” on page 120.

Backing up data of your Sony CLIE Handheld

Backing up your CLIE handheld data using “Memory Stick” media

MS Gate allows you to save a backup of the following application and data of your CLIE handheld to “Memory Stick” media. (The file name after the colon is the name displayed in MS Gate.)

■ Applications

- Plugin files: CmPl###
- PictureGear Pocket: PictureGear Pocket
- gMovie: gMovie
- Network setup data: inetSetup

■ Data

- Address Book data: AddressDB
- Date Book data: DatebookDB
- Memo Pad data: MemoDB
- Expense data: ExpenseDB
- To Do List data: ToDoDB
- Network setup information: NetworkDB
- Other application setting data: SavedPreference
- User information and other preferences data: UnsavedPreference

For details on how to use MS Gate, see “Copying your CLIE handheld data to “Memory Stick” media” on page 153.

Notes

- If necessary files are not backed up, applications may not function properly.
- Do not select Graffiti® ShortCuts, Net Prefs, and sonyres files, since they cannot be copied.
- You cannot copy data marked with a lock  icon.
- You may not be able to back up full information since some data is locked or shared.

Backing up data of your Sony CLIE Handheld

Restoring backup data and applications to your CLIE handheld

Note

When you restore (copy) backup data and applications to your CLIE handheld, the data currently saved in your CLIE handheld will be overwritten with the backup data. Any data created or edited after you saved the backup will be erased.

Insert “Memory Stick” media storing the backup data into your CLIE handheld and use MS Gate to copy the data to your CLIE handheld. For details, see “Copying data in “Memory Stick” media to your CLIE handheld” on page 155.

If an overwrite confirm message is displayed, tap Yes to all.

Notes

- If a delete or access error message is displayed while copying files, tap OK to proceed to the next step in copying. Those files, however, will not be copied.
- Depending on the application configurations or file protection status, some necessary files may not be copied. In such a case, an application may not function properly.
- Some applications are not designed to be backed up. Therefore, you may not be able to restore some applications and data. We recommend you to re-install the application again.

Using data of another Sony CLIE Handheld

If you already own a Sony CLIE Handheld, you can use data of your old CLIE handheld with your new CLIE handheld. You can transfer data from your old CLIE handheld to your new CLIE handheld with either of the following methods:

- **Using Palm™ Desktop for CLIE to copy data:** You can transfer data of the Palm OS basic applications easily.
- **Using “Memory Stick®” media to copy data:** You can transfer all the necessary data and settings information more securely than using the Palm Desktop for CLIE software.

Note on add-on applications that you have installed

Install add-on applications using the same procedures as the previous CLIE handheld. Some third-party applications may operate only on your old CLIE handheld.

Using the Palm Desktop for CLIE software to transfer data

For the Palm OS® basic applications data such as Address Book, Memo Pad, To Do List, Date Book, you can use the Palm Desktop for CLIE software to transfer data from your old CLIE handheld to your new CLIE handheld by exporting and importing data.

Before you start, perform a HotSync® operation to the Palm Desktop for CLIE software using your new CLIE handheld with a different user name from that you have used with the old CLIE handheld.

- 1** Start the Palm Desktop for CLIE software.
- 2** Click the user name of your previous CLIE handheld from the User name list in the upper right of the screen.
- 3** Click the icon of the application whose data you want to copy in the left panel of the screen.
- 4** Click Export from the File menu.
- 5** Enter the file names and click Export.

The data of your old CLIE handheld is exported. Change the destination folder if necessary.

Continued on next page

Using data of another Sony CLIE Handheld

- 6** Repeat steps 3 through 5 to export data of other applications.
- 7** Click the user name of your new CLIE handheld from the User name list in the upper right of the screen.

If you have never performed a HotSync operation with your new CLIE handheld, select Users from the Tools menu. Click New in the Users screen and enter a new user name. Then select that new user name.
- 8** Click Import from the File menu.
- 9** Select the files you have exported in steps 3 through 6 and then click Open.
- 10** Place your new CLIE handheld on the cradle and perform a HotSync operation.

The data exported from your old CLIE handheld is copied onto your new CLIE handheld.

Notes on a HotSync operation

- Do not attempt to transfer data from your old CLIE handheld to your new CLIE handheld by performing HotSync operations with the identical user name. Doing so may cause trouble.
- When you perform a HotSync operation with your new CLIE handheld and the New User dialog box is displayed, enter a different user name from that of your old CLIE handheld. If you enter the identical user name, the Palm Desktop for CLIE software may not be able to recognize the difference between your CLIE handhelds and the data of both handhelds may be mixed up or deleted.
- If you copy UnsavedPreference, the user name is also copied. This prevents you from managing the two CLIE handhelds with different user names.

Using data of another Sony CLIE Handheld

Using “Memory Stick” media to transfer data

You can use “Memory Stick” media to transfer your old CLIE handheld to your new CLIE handheld.

Notes

- Use “Memory Stick” media that has sufficient free memory space.
- Make sure that the write protect tab on “Memory Stick” media is set to the write enable position.

- 1** Insert “Memory Stick” media into your old CLIE handheld.
- 2** Rotate the Jog Dial™ navigator to select MS Gate and then press the Jog Dial navigator. Or tap the MS Gate  icon on the Application Launcher screen.

MS Gate starts up. The data in your CLIE handheld is listed.

- 3** Tap to select the data of the application whose settings and information you want to use with your new CLIE handheld.

You can select multiple files.

- Address Book: AddressDB
- Date Book: DatebookDB
- Memo Pad: MemoDB
- Expense: ExpenseDB
- Mail: MailDB
- To Do List: ToDoDB
- Network setup information: NetworkDB

Notes

- You cannot copy data marked with the lock  icon.
- You cannot copy Graffiti® ShortCuts, Net Prefs, and sonyres (the database for accessing the files in “Memory Stick” media).
- Do not select UnSavedPreference. Your computer may not be able to distinguish your new CLIE handheld from your old CLIE handheld.

Continued on next page

Using data of another Sony CLIE Handheld

4 Tap COPY.

The File Overwrite confirmation message is displayed.

5 Tap OK.

The data selected in step 3 is copied onto “Memory Stick” media.

6 Remove the “Memory Stick” media from your old CLIE handheld and then insert it into your new CLIE handheld.

7 Rotate the Jog Dial navigator to select MS Gate and then press the Jog Dial navigator. Or tap the MS Gate  icon on the Application Launcher screen.

MS Gate starts. The data in your CLIE handheld is listed.

8 Press the Jog Dial navigator to select MS.

You can also tap the arrow ▼ in the upper right corner to select MS from the drop-down list.

9 Tap Select All.

10 Tap COPY.

The File Overwrite confirmation message is displayed.

11 Tap OK.

12 Tap Yes to All.

The data of your old CLIE handheld is copied onto your new CLIE handheld.

Note

If a file-locked, access, or delete error message is displayed while copying files, tap OK to proceed to the next step in copying. Those files, however, will not be copied.

Precautions

Notes on use

- Take care not to scratch or damage your CLIE handheld's screen or the Graffiti® writing area. Always use the supplied stylus or a plastic-tipped pointer to tap on the screen. Do not use a real pen, pencil, or other sharp object on the screen.
- Do not expose your CLIE handheld to rain or moisture. Should water enter the circuitry through the crevice around the front buttons, your CLIE handheld may be damaged.
- Your CLIE handheld screen is made of glass. Do not drop or submit your CLIE handheld to external shock. Do not carry your CLIE handheld in your back pocket. If you sit down with your CLIE handheld in the back pocket, it may break.
- Avoid using or storing your CLIE handheld in locations subject to:
 - extremely high temperature such as the hot inside of a car exposed to the sun, or near a heater.
 - direct sunlight
 - high humidity
 - excessive dust
- The rubber feet of the cradle may lose their adhesion as they become dirty. If this occurs, wipe the feet with a moistened soft cloth to recover their adhesion.

On cleaning

Clean your CLIE handheld with a soft, dry cloth.

Precautions

Battery considerations

Follow these precautions when you charge your CLIE handheld.

On charging

- It takes about four hours to charge your CLIE handheld when the battery is empty.
- When you charge your CLIE handheld every day, it takes only a few minutes to charge the battery.
- You can view data or play audio files on your CLIE handheld while it is being charged.

On the battery life

- With a fully-charged battery, you can use your CLIE handheld for about fifteen days, 30 minutes each day, if you do not use the audio playback function.
- If you set the HOLD switch to OFF and turn on the frontlight at the maximum level, you can play music continuously for about 3 hours.
- If you set the HOLD switch to ON, you can play music continuously for about 11 hours.
- Battery life varies depending on the conditions and environment where you use your CLIE handheld.

Tips on conserving the battery

- Turn off the frontlight under good lighting conditions. For turning off the frontlight, see “Changing the frontlight level” on page 25.
- Change the automatic shut-off time setting so that your CLIE handheld will automatically turn off after a short period of inactivity. For details, see “Setting the automatic shut-off time” on page 172.
- If you play music using Audio Player, the battery may run out quickly.

Continued on next page

Precautions

When your battery runs out

- When the battery runs out, a caution message appears on the screen. If this occurs, perform a HotSync® operation to back up all your CLIE handheld's data on your computer. Then charge your CLIE handheld using the cradle. This helps prevent accidental data loss.
- If your CLIE handheld does not turn on when you press the POWER button, charge your CLIE handheld immediately.
- The remaining battery indicator does not always reflect the actual battery amount. The battery is designed to provide years of service under normal use. To prolong the battery's life, charge it frequently even when it is not fully discharged.
- You do not have to replace batteries. When the remaining battery indicator reads zero, place your CLIE handheld on the cradle and start charging immediately. Never disassemble your CLIE handheld to take out the battery.

When the remaining battery indicator reads 0.

If your battery drains and you leave your CLIE handheld in an uncharged state for an extended period of time, all of the stored data will be erased. Sony suggests you charge your CLIE handheld frequently.

Troubleshooting – Frequently Asked Questions

This section describes how to solve common problems you may encounter when using your CLIE handheld. If a problem arises, we suggest you charge your CLIE handheld. If the problem persists, review the following list of frequently asked questions for possible solutions before you contact Sony Customer Information Service Center.

Note

Thousands of third-party add-on applications are available for the Palm OS® platform. Sony does not support third-party applications. If you have a problem with a third-party application, please contact the developer or publisher of that software.

Operating problems

I do not see anything on my CLIE handheld's screen.

Try each of these in turn:

- ➔ Recharge your CLIE handheld. If your CLIE handheld still does not operate, try a soft reset. See “Resetting your Sony CLIE Handheld” (page 26).
- ➔ Make sure that the HOLD switch is not in the on position.

I get a warning message telling me my CLIE handheld's memory is full.

- ➔ Purge records from Date Book and To Do List. This deletes To Do List items and past Date Book events from the memory of your CLIE handheld.
- ➔ Delete unused memos and records. If necessary, you can save a backup for these records. See explanations for each application.
- ➔ If you have installed additional applications on your CLIE handheld, remove them to recover memory. See “Removing add-on applications” in the Read This First manual.
- ➔ Some applications may not operate properly if the memory is limited.

Continued on next page

Troubleshooting – Frequently Asked Questions

My CLIE handheld keeps turning itself off.

- ➔ Your CLIE handheld is designed to turn itself off after a period of inactivity. This period can be set at one, two, or three minutes. See “Setting the automatic shut-off time” (page 172).

My CLIE handheld is not making any sounds.

- ➔ Check the System Sound setting. See “Setting sounds” (page 173).
- ➔ While you are using the supplied headphones, you cannot hear sound from your CLIE handheld.

My CLIE handheld has frozen.

- ➔ Perform a soft reset. See “Resetting your Sony CLIE Handheld” (page 26).
- ➔ Make sure that the HOLD switch is not in the on position.

I cannot use the Jog Dial navigator.

- ➔ Check that the JogAssist feature is activated. See “Changing the Jog Dial™ navigator preferences” (page 167).

An error message is displayed repeatedly.

- ➔ Follow the instructions of the message.

Frontlight turns on when I am adjusting the frontlight level.

- ➔ When you are adjusting the frontlight level, the LCD frontlight turns on.

Troubleshooting – Frequently Asked Questions

Tapping and writing problems

When I tap the buttons or screen icons, my CLIE handheld activates the wrong feature.

- ➔ Calibrate the screen. See “What you can do with Preferences” (page 162).

When I tap the Menu icon, nothing happens.

- ➔ Not all applications or screens have menus. Try changing to a different application.

I cannot get my CLIE handheld to recognize my handwriting.

- ➔ For your CLIE handheld to recognize handwriting input with the stylus, you need to use Graffiti® writing. See “Using Graffiti® writing to enter data” (page 13).
- ➔ Make the Graffiti character strokes in the Graffiti writing area, not on the display part of the screen.
- ➔ Write Graffiti strokes for letters on the left-hand side, and the strokes for numbers on the right-hand side of the Graffiti writing area.
- ➔ Make sure that Graffiti has not shifted into extended or punctuation modes. See “Using Graffiti® writing to enter data” (page 13).
- ➔ For tips on successful Graffiti writing, see “Using Graffiti® writing to enter data” (page 13).

Troubleshooting – Frequently Asked Questions

Application problems

I tapped the Today button, but it does not show the correct date.

- ➔ Your CLIE handheld is not set to the current date. Make sure the Set Date box in the General Preferences screen displays the current date. See “Setting the General preferences” (page 170).

I know I entered some records, but they do not appear in the application.

- ➔ Check the Categories drop-down list (upper-right corner). Choose All to display all of the records for the application.
- ➔ Check Security and confirm that Current Privacy is set to Show Records.
- ➔ In To Do List, tap Show and see if “Show Only Due Items” is selected.

I am having problems listing memos the way I want to see them.

- ➔ If you cannot manually arrange the order of the memos in the list screen, check the Memo Preferences setting. Make sure that Sort by is set to Manual.
- ➔ If you choose to view your memos alphabetically on the Palm™ Desktop for CLIE software and then perform a HotSync® operation, the memos on your CLIE handheld still appear in the order defined in the Memo Preferences setting. In other words, the sort settings you use with the Palm Desktop for CLIE software are not transferred to your CLIE handheld.

I created an event in Date Book, but it does not appear in the Week view.

- ➔ In the Week view, you cannot select overlapping events that have the same start time. If you have two or more events with the same start time, choose the Day view to see overlapping events.

Continued on next page

Troubleshooting – Frequently Asked Questions

I cannot find an image pasted in an Address Book record.

- ➔ If you use the Palm Desktop for CLIE software to change the category of the Address Book record, you may not be able to locate the pasted image on your CLIE handheld. Change the category on your CLIE handheld.

I changed Currencies in Expense, but they do not appear in the application.

- ➔ Retry setting Currencies in the Select Currencies dialog box.

HotSync problems

I cannot perform a HotSync operation. What should I check to make sure I am doing it correctly?

- ➔ Check that the operating system of your computer is Windows® 98/98SE/Me/2000 Professional.
- ➔ Check the Windows task tray to make sure the HotSync Manager and USB Switcher are running. If they are not running, open HotSync Manager and USB Switcher from the Start menu.
- ➔ Make sure the cradle is connected securely to the computer.

I performed a HotSync operation, but one of my applications did not synchronize.

- ➔ Click the HotSync Manager and choose Custom. Check that the correct conduit is active.

Continued on next page

Troubleshooting – Frequently Asked Questions

I am using Outlook® as my PIM, but I cannot do a HotSync operation.

- ➔ Click the HotSync Manager and choose Custom. Check that the correct conduit is active.
- ➔ Check that the correct conduit is installed. Reinstall the HotSync Manager and make sure the correct conduit is selected.
- ➔ Make sure that Intellisync Lite is installed. See “Step 4: Installing the Palm Desktop for CLIE software onto your computer” in the Read This First manual for details.

I cannot launch the HotSync Manager.

- ➔ Make sure you are not running another program, such as a network or facsimile applications, that use the serial port you selected in the Setup dialog box.
- ➔ Back up the Palm Desktop for CLIE software, uninstall it, and then reinstall it.
- ➔ Make sure that Local is not selected.

I tried to perform a local HotSync operation, but it did not complete successfully.

Try each of these in turn:

- ➔ Make sure that the USB Switcher is running.
- ➔ Make sure HotSync Manager is running. If HotSync Manager is running, exit, and then restart it.
- ➔ Make sure that Local is not selected in the HotSync Manager menu or the Palm Desktop for CLIE software menu.
- ➔ Check that the cradle is properly connected to the USB connector of your computer.
- ➔ Read the HotSync Log for the user account for which you are performing a HotSync operation.

Continued on next page

Troubleshooting – Frequently Asked Questions

- ➔ Make sure your CLIE handheld is seated in the cradle correctly.
- ➔ Make sure the gold-plated connectors on the cradle and your CLIE handheld are clean. Use a pencil eraser to clean them.

I cannot perform a HotSync operation via modem.

Check the following on your computer:

- ➔ Make sure your computer is turned on and that it does not shut down automatically as part of an energy-saving feature.
- ➔ Make sure the modem connected to your computer is turned on and is connected to the outgoing phone line.
- ➔ Make sure Modem is selected in the HotSync Manager menu.
- ➔ Make sure the modem you are using with your CLIE handheld has an on-off switch. Your CLIE handheld cannot “wake up” a modem that has an auto-off feature.
- ➔ Make sure the modem is connected properly to a serial port on your computer and it is connected to an incoming phone line.
- ➔ Confirm that the Setup String in the Setup dialog box configures your modem correctly. You may need to select a different Modem Type or enter a custom Setup String.
- ➔ Confirm that the Speed setting in the Setup dialog box works for your modem. If you have problems using the “As Fast As Possible” option or a specific speed, try using a slower speed.
- ➔ Make sure your modem resets before you try again. (Turn off your modem, wait a minute, then turn it on.)
- ➔ Confirm that the telephone cable is securely attached to your modem.
- ➔ Make sure the dialing instruction dials the correct phone number.
- ➔ If you need to dial an outside line prefix, make sure you selected the Dial Prefix option on your CLIE handheld and have entered the correct code.

Continued on next page

Troubleshooting – Frequently Asked Questions

Check the following on your CLIE handheld:

- ➔ If the telephone line you are using has Call Waiting, make sure you selected the Disable call waiting option under “Modem Sync Phone Setup” on your CLIE handheld and entered the correct code.
- ➔ Make sure the telephone line you are using is not noisy. This can interrupt communications.
- ➔ Check the batteries in your modem and replace them if necessary.

I cannot perform an IR HotSync operation.

- ➔ Make sure that the HotSync Manager is running and the Serial Port for local operations is set to the simulated port for infrared communication.
- ➔ On your CLIE handheld, make sure that the HotSync application is set to IR to a PC/Handheld.
- ➔ Make sure that the IR port of your CLIE handheld is aligned directly opposite to, and within a few inches of, the infrared device of your computer.
- ➔ IR HotSync operations do not work after you receive a low battery warning. Check the battery power of your CLIE handheld. Recharge the battery if necessary.
- ➔ If you have problems using a specific speed, select Prefs, Connection, IR to a PC/Handheld, Edit, and then Details. Then select a lower speed in the Details dialog box.

My CLIE handheld appears to freeze when I place it near my computer.

- ➔ Move your CLIE handheld away from the computer’s infrared port.
- ➔ Make sure that you turn the Beam Receive function off.

Continued on next page

Troubleshooting – Frequently Asked Questions

My CLIE handheld displays the message “Waiting for sender” when it is near my computer’s infrared port.

- ➔ Your computer’s infrared port may be set to search automatically for the presence of other infrared devices. Do the following to turn off this option:
 - 1 In the Windows task bar, select Start, point to Settings, and then select Control Panel.
 - 2 Double-click Infrared.
 - 3 Click the Options tab.
 - 4 Clear the selection of the option “Search for and provide status for devices within range.”
 - 5 Click Apply and OK.
- ➔ Move your CLIE handheld away from the computer’s infrared port.
- ➔ Make sure that you turn the Beam Receive function off.

I cannot cancel a HotSync operation midway.

- ➔ You may not be able to cancel a job a few seconds after you start a HotSync operation via a USB connection. Wait for a while and try again.

I cannot backup some data at a HotSync operation.

- ➔ Some data is designed not to be backed up by a HotSync operation.

When I tap the HotSync button on the cradle, nothing happens on the Palm Desktop for CLIE software and my CLIE handheld times out.

- ➔ Check the Palm Desktop for CLIE software HotSync Setup options to confirm that you have the correct settings for local HotSync operations.
- ➔ Close and restart HotSync Manager and USB Switcher on your computer.

Continued on next page

Troubleshooting – Frequently Asked Questions

- ➔ Make a copy of your Palm folder. Uninstall, and then reinstall the Palm Desktop for CLIE software.
- ➔ Turn on your CLIE handheld and then tap the Home  icon. Tap the HotSync icon, then tap Local.

When I perform a HotSync operation, my information does not transfer to the Palm Desktop for CLIE software.

- ➔ If you have performed a HotSync operation successfully, but you cannot find the data from your CLIE handheld on the Palm Desktop for CLIE software, check to see that you have the correct user name selected for viewing data.
- ➔ Click the HotSync Manager and then choose Custom. Check that all conduits are set to synchronize files.

I want to synchronize my computer with more than one CLIE handheld.

- ➔ When the computer running the Palm Desktop for CLIE software is to synchronize with more than one CLIE handheld, each CLIE handheld must have a unique user name. Assign a unique user name to your CLIE handheld the first time you perform a HotSync operation.
- ➔ Please be aware that synchronizing with more than one CLIE handheld with the same user name causes unpredictable results, and potentially, loss of your personal information.

Troubleshooting – Frequently Asked Questions

Beaming problems

I cannot beam data to another Palm OS PDA.

- ➔ Confirm that your CLIE handheld and the other Palm OS PDA are between 4 inches (approximately 10 centimeters) and 8 inches (approximately 20 centimeters) apart, and that the path between the two handhelds is clear of obstacles. Beaming distance to other Palm OS PDA may be different.
- ➔ Move your CLIE handheld closer to the receiving handheld.
- ➔ Make sure that the Beam Receive function of the other Palm OS PDA is turned on.

When someone beams data to my CLIE handheld, I get a message telling me it is out of memory.

- ➔ Your CLIE handheld requires at least twice the amount of memory available as the data you are receiving. For example, if you are receiving a 30K application, you must have at least 60K free.
- ➔ Perform a soft reset. See “Resetting your Sony CLIE Handheld” (page 26) for more information.

I cannot beam Address Book data.

- ➔ You cannot beam Address Book data to a CLIE handheld in which Address Book has never been started. Start Address Book and then try beaming Address Book data again.
- ➔ You cannot beam images to a Palm OS PDA other than a Sony CLIE handheld.

Troubleshooting – Frequently Asked Questions

Recharging problems

When I place my CLIE handheld in the cradle, it does not recharge.

- ➔ Confirm that your CLIE handheld is well seated in the cradle.
- ➔ Confirm that your cradle is plugged into an AC power adapter.
- ➔ Confirm that you are using the cradle and AC adapter that came with your CLIE handheld.
- ➔ Confirm your CLIE handheld is turned off. Otherwise, it will not fully charge.

Password problems

I forgot the password, and my CLIE handheld is not locked.

- ➔ You can use Security to delete the password, but your CLIE handheld deletes all records marked as private. To back up all data including private records, perform a HotSync operation before you delete the password. Then follow these steps to restore your private records onto your CLIE handheld:
 - 1 Perform a HotSync operation to back up your data.
 - 2 Tap Forgotten Password in Security to remove the password and delete all private records.
 - 3 Perform a HotSync operation to synchronize your data and restore the private records by transferring them from your computer to your CLIE handheld.

I forgot the password and my CLIE handheld is locked.

- ➔ If you assign a password and lock your CLIE handheld, you must perform a hard reset to continue using your CLIE handheld. See “Resetting your Sony CLIE Handheld” (**on page 26**) for more information.

Troubleshooting – Frequently Asked Questions

“Memory Stick®” media problems

I cannot copy/move data from “Memory Stick®” media to my CLIE handheld.

- ➔ Your CLIE handheld requires at least twice the amount of memory available as the data you are copying/moving. For example, if you are copying/moving a 30K application, you must have at least 60K free.

I inserted “Memory Stick” media, but the message “Please insert Memory Stick media” appears.

- ➔ Your “Memory Stick” media is not recognized by your CLIE handheld. Remove it and insert it again.

Troubleshooting – Frequently Asked Questions

If you cannot perform a HotSync operation

If you have reviewed the items in the Troubleshooting list and the HotSync problem persists, try the following procedures to perform a HotSync operation.

Check that the device driver is working properly

Under Windows 2000 Professional

- 1** Right-click the My Computer icon and then click Properties from the shortcut menu.
The System Properties window is displayed.
- 2** Click the Hardware tab and then click the Device Manager button.
- 3** Click  the of Port (COM & LPT).
The  changes to  and the Port details are displayed.
- 4** Press the HotSync button on the cradle.
When the device driver functions properly, SonyPEG Virtual Port (COM*) appears.
 - If a “!” or an “X” mark is displayed, go to step 5 to remove the driver.
 - If SonyPEG is displayed properly, follow the procedures in “Checking for an unnecessary device driver in the Device Manager tab” later in this section.
- 5** Click USB Switcher in the Windows task tray and then select Exit from the shortcut menu.
- 6** Right-click SonyPEG (COM*) and then select Remove while SonyPEG (COM*) is displayed.
The SonyPEG is displayed only for less than a minute after you press the HotSync button.
- 7** Click OK and then remove your CLIE handheld from the cradle.
- 8** Perform a soft reset of your CLIE handheld.
- 9** Restart your computer.
- 10** Place your CLIE handheld on the cradle and then press the HotSync button.

Troubleshooting – Frequently Asked Questions

Under Windows 98/98SE/Me

- 1 Right-click the My Computer icon and then click Properties from the shortcut menu.

The System Properties window is displayed.

- 2 Click the Device Manager tab.
- 3 Press the HotSync button on the cradle.
- 4 If nothing happens in the Device Manager window, click Refresh.
- 5 Click the  of Port (COM & LPT) and Universal serial bus controller.

The  changes to .

When the device driver functions properly, SonyPEG Virtual Port (COM*) and Sony PEG appear.

- If a “!” or an “X” mark is displayed, go to step 6 to remove the driver and then reinstall it.
 - If SonyPEG Virtual Port is displayed properly, follow the procedures in “Checking for an unnecessary device driver in the Device Manager tab” later in this section.
- 6 Click USB Switcher in the Windows task tray and then select Exit from the shortcut menu.
 - 7 Right-click SonyPEG Virtual Port (COM*) and then select Remove while it is displayed.
The SonyPEG Virtual Port is displayed only for less than a minute after you press the HotSync button.
 - 8 Right-click SonyPEG and then select Remove while it is displayed.
The Sony PEG is also displayed only for less than a minute after you press the HotSync button.

Tip

When you start Windows in Safe mode, you can remove SonyPEG Virtual Port and SonyPEG easily since they are displayed without pressing the HotSync button. For details on Safe mode, see the Windows documentation.

Continued on next page

Troubleshooting – Frequently Asked Questions

- 9** Click OK and then remove your CLIE handheld from the cradle.
- 10** Perform a soft reset of your CLIE handheld.
- 11** Restart your computer.
- 12** Place your CLIE handheld on the cradle and then press the HotSync button.

Checking for an unnecessary device driver in the Device Manager tab

- 1** Right-click the My Computer icon and then click Properties from the shortcut menu.

The System Properties window is displayed.

- 2**
 - When using Windows 2000 Professional, click the Hardware tab and then click the Device Manager button.
 - When using Windows 98/98SE/Me, click the Device Manager tab.

- 3** Check to see if there is a device with the “!” or “X” mark in the list.

A device with one of the marks will not operate properly and may affect the USB Switcher operation. Remove the device or contact the supplier of the driver about upgrading the driver.

Continued on next page

Troubleshooting – Frequently Asked Questions

You cannot perform a HotSync operation before you install the Palm Desktop for CLIE software onto your computer

If you perform a HotSync operation before you install the CLIE drivers, other drivers may be installed. Make sure to install the Palm Desktop for CLIE software first and then perform a HotSync operation.

Do not use a USB hub

If you connect the cradle to your computer via a USB hub, you may not be able to perform a HotSync operation properly. Make sure to connect the cradle directly to a USB connector of your computer.

Some computers have the hub function built into their internal circuitry. Contact your computer manufacturer if the USB connector of your computer is connected to an internal USB hub.

Check the USB driver being used

If you are using or have used a communication device that uses a virtual COM port, its driver may conflict with the driver for your CLIE handheld, preventing a HotSync operation. Remove the relevant driver or reinstall the driver for your CLIE handheld. Or reinstall all software on your computer.

Check that the USB port of your computer is enabled

If you are using Windows 95 pre-installed computer or another old type of computer equipped with a USB port, the USB port may be disabled by default. If another device such as a USB mouse cannot be used, check the BIOS setting of your computer.

Also check the Device Manager. Right-click on My Computer and then select Properties. Click Device Manager tab and check that USB controller is listed in the Device Manager screen.

Getting Help

Sony offers several support options for your CLIE handheld. When you have questions or trouble, please refer to one of the following for a solution:

- **Read This First (supplied), Operating Instructions (this guide), and Add-on Application Guide (supplied)** explain how to use your CLIE handheld.
- **Your Sony CLIE Handheld support Web site**
<http://www.sony.com/peg/support/>
Provides the latest information on your CLIE handheld. On this Web site, you will find:
 - Frequently Asked Questions (FAQs)
 - Online Operating Instructions
 - Installation information
 - Software updates
 - Online knowledge base
- **The Sony e-mail support service** answers your questions by e-mail. Send your question, and a customer service representative will send you a reply. You can use the e-mail form at <http://www.sony.com/peg/support/>.
- **The Sony fax-back service** provides you with answers to commonly asked questions. You can use this automated service to request a list of available topics and then select the topics that you want to receive. To contact the Sony fax-back service, call 1-877-760-SONY (7669) .
- **The Sony Customer Information Service Center** offers information about your CLIE handheld and other Sony products that work with your computer. To contact the Sony Customer Information Service Center, call 1-877-760-SONY (7669) .

Specifications

OS Palm OS ver. 3.5

CPU Dragonball VZ 33MHz

Memory

8 MB (DRAM)

4 MB (Flash memory)

User memory range:

approx. 7 MB

External input/output

Interface connector

IrDA (1.2)

Memory Stick slot

LCD display

Frontlight TFT color display

320 × 320 dots, 256 colors

Power requirements

AC power adapter (supplied)

DC5.7V

(dedicated connector)

Battery

Lithium ion battery

(built-in)

Battery life

15 days* (based on an average of 30 minutes use per day)

Approx. 11 hours (in operation with LCD off)*

Approx. 3 hours (in operation with LCD on)*

Audio frequency response

20 Hz to 20,000 Hz

Audio recording time (when using a 128 MB “Memory Stick” media)

Approx. 120 min.

(bit rate: 132kbps)

Approx. 160 min.

(bit rate: 105kbps)

Approx. 240 min.

(bit rate: 66kbps)

Audio Recording format

ATRAC3**

MP3

Sampling frequency

44.1 kHz

Output

Headphones: stereo mini-jack

Dimensions

Approx. $2\frac{7}{8} \times 4\frac{3}{4} \times 11\frac{1}{16}$ inches (71.0 × 118.5 × 16.8 mm) (w/h/d)

Mass

Approx. 5.65 oz (160g) (including the supplied stylus)

Operating temperature

41°F - 95°F (5°C - 35°C)

* The battery life span varies depending on the temperature and conditions of use.

** The ATRAC3 content-protected music is supported when used with “MagicGate Memory Stick” media (not supplied).

Design and specifications are subject to change without notice.

Limited Warranty Statement

Sony Personal Entertainment Organizer Warranty

The limited warranty on your hardware covers parts and labor against defects in material or workmanship for a period of three months from the original date of purchase. You can extend the warranty period for an additional nine months by registering your CLIE handheld. See “Customer registration” in *Read This First*. Once you register your CLIE handheld, the limited warranty period is twelve months from the original date of purchase.

For the purpose of this Limited Warranty “SONY” means SONY ELECTRONICS INC. for Products purchased in the United States of America. SONY warrants this CLIE handheld hardware product (“the Product”) against defects in material or workmanship as follows:

1. Labor: For a period of ninety (90) calendar days from the original date of purchase from SONY or a SONY authorized reseller, SONY will repair defects in material or workmanship in the Product at no charge, or pay the associated labor charges to a SONY authorized service facility. The ninety (90) day warranty period is extendible only to the original purchaser, for an additional period of nine (9) months, for a total of twelve (12) months from date of purchase when the Product is registered electronically prior to the expiry of ninety (90) days from the original date of purchase. After the applicable period you must pay for all labor charges.
2. Parts: For a period of ninety (90) calendar days from the original date of purchase from SONY or a SONY authorized reseller, SONY will supply, at no charge, new or rebuilt, at SONY’s option, replacement parts in exchange for defective parts. Any replacement parts will be warranted for the remainder of the original warranty period or ninety (90) calendar days from installation by SONY’s authorized service facility, whichever is longer. The ninety (90) day warranty period is extendible only to the original purchaser, for an additional period of nine (9) months, for a total of twelve (12) months from date of purchase when the Product is registered prior to the expiry of ninety (90) days from the original date of purchase. All defective parts replaced under this Limited Warranty will become the property of SONY.

Limited Warranty Statement

This Limited Warranty covers only the hardware components packaged with the Product. It does not cover the technical assistance for hardware or software usage and it does not cover any software products whether or not contained in the Product. SONY excludes all warranties express or implied in respect of any software provided with the product and any such software is provided AS IS unless expressly provided for in any enclosed software limited warranty. Please refer to the End User License Agreements included with the Product for your rights and obligations with respect to the software.

This Limited Warranty is non-transferable. Proof of purchase in the form of a bill of sale (which is evidence that the Product is within the warranty period) must be presented to obtain warranty service. In addition, if replacement parts are required and you wish to receive the most expedient service available, you will be required to provide SONY with a credit card authorization to bill your credit card in the event you fail to return the original parts in the postage-paid envelope we provide. The credit card will only be charged for SONY's list price for the part if the original part has not been returned within thirty (30) days.

With respect of certain components you may be entitled to express warranty service during the warranty period, subject to certain restriction. Please contact SONY as indicated below for further information.

With respect to all service provided, it is your responsibility prior to Product service to backup the data stored in its memory. It is likely that the contents of the memory will be lost or reformatted in the course of service and SONY will not be responsible for any damage to or loss of any programs, data or other information stored on any media or any part of any Product serviced hereunder or any consequential damages resulting therefrom.

IF DURING THE REPAIR OF THE PRODUCT THE CONTENTS OF THE MEMORY ARE ALTERED, DELETED OR IN ANY WAY MODIFIED, SONY IS NOT RESPONSIBLE WHATSOEVER. YOUR PRODUCT WILL BE RETURNED TO YOU CONFIGURED AS ORIGINALLY PURCHASED (SUBJECT TO AVAILABILITY OF SOFTWARE AND ANY SUBSEQUENT REVISION).

Be sure to remove all third party hardware, software, features, parts, options, alterations, and attachments not warranted by SONY prior to sending the Product to SONY for service. SONY is not liable for any loss or damage to these items.

Limited Warranty Statement

This Limited Warranty does not cover any consumable items supplied with the Product; cosmetic damages; damage or loss to any software programs, data, or media; or damage due to (1) acts of God, accident, misuse, abuse, negligence, commercial use or modifications of this Product; (2) improper operation or maintenance of this Product; (3) connection to improper voltage supply; or (4) attempted repair by any party other than a SONY authorized service facility. This warranty does not cover physical damage to the surface of the product, including cracks or scratches on the LCD touchscreen or outside casing. This Limited Warranty does not apply when the malfunction results from the use of the Product in conjunction with accessories, products or ancillary or peripheral equipment, or where it is determined by SONY that there is no fault with the Product itself. This Limited Warranty is valid only in the United States of America. This Limited Warranty is invalid if the factory-applied serial number has been altered or removed from the product.

Repair or replacement of defective parts or hardware as provided under this Limited Warranty is the exclusive remedy of the consumer. SONY SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES OR OTHER DAMAGES INCLUDING BUT NOT LIMITED TO, LOSS OF PROFITS, LOSS OF REVENUE, LOSS OF DATA, LOSS OF USE OF THE PRODUCT OR ANY ASSOCIATED EQUIPMENT, DOWNTIME AND PURCHASER'S TIME OR FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY OR ANY OTHER LEGAL THEORY RELATED TO THIS PRODUCT. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This Limited Warranty gives you specified legal rights, and you may have other rights which vary from state to state.

Limited Warranty Statement

Technical Support: Although technical support is not provided free of charge under this Limited Warranty, SONY has established a telephone number for technical support. Charges may apply for technical support, unless and to the extent that free technical support for a limited period is provided in writing as a feature of your Product. Prior to placing your call, please have available the model and serial number for your Product, date of purchase, a list of all options installed in your Product and a detailed description of the problem.

For Product support, online knowledge base, frequently asked questions, and free updates via the Internet: <http://www.sony.com/peg/support/>. For Product information, service assistance, resolution of a service problem, or technical assistance, call 1-877-760-SONY (7669).

Save this for future reference.

© 2001 Sony Electronics Inc. Reproduction in whole or in part without written permission is prohibited. All rights reserved. SONY is a registered trademark of Sony Corporation.

It Is Important That You Register Your Personal Entertainment Organizer

By registering, you receive the following benefits:

- Your 90-day limited hardware warranty is automatically extended to a full year from the original date of purchase.
- One Year Hardware Telephone Support.

Index

A

Address Book	
Editing entries	57
Entering a new entry	49
Pasting an image	55
Sorting entries	53
Using menus	61
Viewing entries	51
Adjusting the frontlight level	25
Application	
Categorizing	92
Displaying in list	93
Displaying pop-up menus	94
Launcher (home) screen	91
Starting/Selecting	91
Troubleshooting	193
Application buttons	
Assigning applications to buttons	164
Starting applications	91
Attaching notes	108

B

BACK button	51, 72
Backing up data	
By a HotSync operation	180
By "Memory Stick" media	181
Battery considerations	
Tips and notes	188
Troubleshooting	201
Battery life	188
Beam Receive feature	174

Beaming

Between two handhelds	140
Receiving data	142
Sending items or categories	141
Tips on beaming between two handhelds	142
Troubleshooting	200

C

Calculator

Using Calculator	89
Using menus	90

Categories

Categorizing items	77, 95
Making a new category	97
Viewing items by category	52, 64, 74

Cleaning

Conduit

Copying

Copying data and applications to your CLIE handheld	182
Copying data from "Memory Stick" media to your CLIE handheld	155
Copying data to "Memory Stick" media	153

Cradle

Currencies

Continued on next page

Index

D

Date Book	
Agenda view	40
Continuous/repeating events	32
Day view	36
Editing	42
Month view	39
Scheduling an event	29
Setting alarm	44
Using menus	47
Week view	37
Deleting	
Data in “Memory Stick” media	157
Items	46, 68, 76
Digitizer	162
Dragging	11

E

Edit menu	110
Entering data	
Computer keyboard	24
Graffiti writing	13, 14
Onscreen keyboard	22
Expense	
Currencies list	85
Editing items	82
Recording new items	79
Using menus	88
Viewing items	81

F

FAQ(Frequently Asked Questions)	190
File Link	138
Finding items	
Find option	98
Phone LookUp	100
Formats	168
Frontlight	
Adjusting the level	25
Turning on and off	25
Full-screen dragging	11, 15, 165

G

Getting Help	207
Graffiti writing	
Accented characters	20
Alphabets	16
Basic procedures	14
Letters/numbers writing areas	13
Navigation strokes	21
Non-English characters	20
Numbers	17
Onscreen help	15
Overview	13
Punctuation marks	18
ShortCuts	21, 176
Symbol or extended characters	19

Continued on next page

Index

H

- Hard reset 27
- High Resolution Assist function 178
- HOLD switch 9
- Home icon 91
- HotSync button 114, 118, 166
- HotSync operation
 - Changing a user name 115
 - Creating a user profile for multiple CLIE handheld 122
 - File Link 138
 - If you cannot perform a HotSync operation 203
 - Overview 113
 - Selecting a Conduit 120
 - Troubleshooting 194
 - Via Cradle (Local HotSync) 114
 - Via IR ports 124
 - Via modem 127
 - Via network 133

I

- Importing data from Windows applications 24, 136
- IR port 140

J

- Jog Dial navigator
 - Changing preferences 167
 - Compatible applications 12
 - How to use (pressing/rotating) 12
 - JogAssist function 167

L

- Limited Warranty Statement 209
- Locking your CLIE handheld 105
- LookUp 54

M

- Making items private .. 45, 77, 102, 105
- Memo Pad
 - Creating new memos 71
 - Editing memos 76
 - Sorting memos 74
 - Using menus 78
 - Viewing memos 73
- “Memory Stick” indicator 144
- “Memory Stick” media
 - Formatting 147
 - Inserting and removing 144
 - Overview 143
 - Protecting data 146
 - Troubleshooting 202
 - Types 143
- MS Gate
 - Copying CLIE data to “Memory Stick” media 153
 - Copying data to your CLIE handheld 155
 - Deleting data 157
 - Formatting “Memory Stick” media 147
 - Starting 149
 - Transferring data between two CLIE handhelds 185
 - Using menus 159

Continued on next page

Index

N

Notes on use 108, 187

O

Onscreen keyboard 22

Owner information 175

P

Palm Desktop for CLIE

Basic operations 116

Locating screen components 117

Starting 116

Password

Entering a password 103

Troubleshooting 201

Performing a reset. *See* Reset

Phone LookUp 100

PIM (Personal Information Management)

Address Book 49

Calculator 89

Common tasks 91

Date Book 29

Expense 79

Memo Pad 71

To Do List 63

Using Edit menu 110

POWER button 9

Precautions 187

Preferences

Beam Receive feature 174

Buttons 164

Digitizer 162

Display formats 168

Full-screen pen stroke activities 165

General preferences 170

Graffiti ShortCuts 176

High Resolution Assist function 178

HotSync button 166

Jog Dial navigator 167

Overview 162

Owner information 175

Time, date, and numbers formats 169

Purging items 109

R

Reset

Hard reset 27

Reset button 27

Soft reset 26

Continued on next page

Index

S

Security	102
Selecting text in an application	110
Setting	
Date	171
Password	103
Sounds	173
Time	170
Soft reset	26
Sorting items	53
Specifications	208
Stylus	
How to use	10
Taking out the reset tip	26

T

Tapping	10
To Do List	
Changing appearances	69
Checking off items	65
Creating items	63
Setting priorities	66
Setting the due date	67
Using menus	70
Viewing items	64
Transferring data between two CLIE handhelds	
Using "Memory Stick" media	185
Using Palm Desktop for CLIE	183

Troubleshooting

Applications	193
Beaming	200
HotSync operations	194
"Memory Stick" media	202
Operations	190
Password	201
Recharging	201
Tapping and writing	192
Turning on and off your CLIE handheld	9

U

USB driver	206
User name	115, 122
Using multiple CLIE handhelds	122, 183
Using the stylus	10

For the latest support information,
check our official Sony CLIE Web site

<http://www.sony.com/clie>

<http://www.world.sony.com/>